


OWNER'S MANUAL
SPXMAS3

Animated Skating Pond



Important Safeguards


1. Do not mount or support the unit in any manner that might cut or damage the wire insulation.
2. Do not connect the unit to any other electrical apparatus.
3. Do not use this product for other than intended use.
4. **THIS IS NOT A TOY!** To avoid the risk of fire, burns or personal injury and electrical shock, it should be placed out of children's reach.
5. This product is intended for indoor use only.
6. Do not use light bulbs larger than 2.5 V.
7. Close supervision is necessary when this product is used near children.

THIS APPLIANCE IS FOR HOUSEHOLD USE ONLY
SAVE THESE INSTRUCTIONS





Getting to Know Your Animated Skating Pond



1. Santa's Workshop
2. Mail Box
3. Fence
4. Skating Pond Base
5. Tree
6. Skating Figurine (Rudolph)
7. Skating Figurine (Mrs. Claus)
8. Skating Figurine (Santa Claus)
9. Sign (North Pole)
10. Elf (making snow angel)
11. Tree
12. AC Adapter (not shown)

Assembly / Operating Instructions

1. Remove all components carefully from polyfoam insert.
2. This product can be powered by 4 "C" alkaline batteries (not included) or by an electrical AC Adapter (not included):*

*Optional AC Adapter can be purchased through our Customer Service Department, Part #80006.

To Run The Unit With Batteries

- Turn the Skating Pond Base upside down and unscrew the Battery Compartment Door. Insert the batteries into the positions indicated.
- Screw the Battery Compartment Door back on, turn the unit right side up, and place it on a flat surface.

To Run The Unit With An AC Adapter

- Place the unit onto a flat, smooth surface. Insert the Skating Pond components as described below. Plug the Jack of the AC Adapter into the plug located at the back of the Pond Base. Plug the AC Adapter into a 120V AC electrical wall outlet and then turn the Switch to the "**ON**" position. By inserting the AC Adapter into the Skating Pond Base, this automatically disconnects the battery source.

NOTE: We recommend removing the batteries when the AC Adapter is being used.

3. The Light Bulb is already in place. If the Light does not illuminate when the Switch is turned "**ON**," unscrew and remove the Bulb Cover and tighten the Bulb. If you are using an AC Adapter, make sure the unit is turned "**OFF**" and unplugged before touching the Bulb. (*See User Maintenance Instructions for special instructions when changing the Light Bulb.)
4. Place Santa's Workshop (1) over the Bulb Cover.
5. Insert the Trees (5 & 11) into the holes as shown in the diagram on page 2.





Assembly / Operating Instructions (continued)

6. Insert the Fence (3) into the three holes located on the left side of the Skating Pond, next to the Tree (5).
7. Insert the Sign (9) into the hole at the front of the Skating Pond Base. Insert the Mail Box (2) into the hole next to Santa's Workshop.
8. Place the Elf making the snow angel (10) onto the Skating Pond Base next to the Tree (11).
(See diagram on page 2.)
9. The Skating Pond has three skating surfaces to place Santa (8), Mrs. Claus (7) and Rudolph (6).
DO NOT PLACE MORE THAN ONE FIGURE ON THE SAME TRACK. After the Figures are placed on their tracks, turn on the unit.

Note: If the Figures do not move right away, wait a moment and they will begin moving on the track.

Note: If the Figures do not move at all, gently move them by hand on the track until they connect.

*For best results...*periodically dust the skating surface with a dry cloth. **Dust can affect the movement of the skaters.**

10. Your Animated Skating Pond works with or without music.

To operate with lights/motion, push the Switch to the first position.

To operate with lights/motion/music, push the Switch to the second position.

*For best results...*place all of the accessories as shown in the diagram on page 2.

User Maintenance Instructions

Replacing the Bulb

1. Make sure the unit is turned off when replacing the Bulb. Always unplug this product before installing or replacing Bulbs when using an AC Adapter.
2. Remove Bulb Cover and unscrew Bulb.
3. Insert a new 2.5 volt screw-in type Bulb into the socket and turn the unit **“ON”** to make sure that the Bulb is inserted properly. Screw the Bulb Cover back on.

CAUTION: To reduce the risk of overheating, replace burned-out Bulbs promptly.





IMPORTANT NOTICE

If any parts are missing or defective,

DO NOT *return this product.*

Please call our Customer Service Department for assistance.

800-233-9054 *Monday - Friday 8am - 5pm CST*

Thank You

ONE-YEAR LIMITED WARRANTY

This Salton/MAXIM product warranty extends to the original consumer purchaser of the product.

Warranty Duration: This product is warranted to the original consumer purchaser for a period of one (1) year from the original purchase date.

Warranty Coverage: This product is warranted against defective materials or workmanship. This warranty is void if the product has been damaged by accident, in shipment, unreasonable use, misuse, neglect, improper service, commercial use, repairs by unauthorized personnel or other causes not arising out of defects in materials or workmanship. This warranty is effective only if the product is purchased and operated in the USA, and does not extend to any units which have been used in violation of written instructions furnished by Salton/MAXIM Housewares, Inc., or to units which have been altered or modified or to damage to products or parts thereof which have had the serial number removed, altered, defaced or rendered illegible.

Warranty Disclaimers: This warranty is in lieu of all warranties expressed or implied and no representative or person is authorized to assume for Salton/MAXIM Housewares, Inc. any other liability in connection with the sale of our products. There shall be no claims for defects or failure of performance or product failure under any theory of tort, contract or commercial law including, but not limited to, negligence, gross negligence, strict liability, breach of warranty and breach of contract.

Warranty Performance: During the above one-year warranty period, a product with a defect will be either repaired or replaced with a reconditioned comparable model (at Salton/MAXIM's option) when the product is returned to the Salton/MAXIM facility. The repaired or replacement product will be in warranty for the balance of the one-year warranty period and an additional one-month period. No charge will be made for such repair or replacement.

Service and Repair

Should the appliance malfunction, you should first call toll-free 1-800-233-9054 **between the hours of 8:00 am and 5:00 pm Central Standard Time** and ask for CUSTOMER SERVICE stating that you are a consumer with a problem.

In-Warranty Service (USA) for an appliance covered under the warranty period, no charge is made for service or postage. Call for pre-paid return mailing label. (U.S. Customers Only)

In-Warranty Service (Canada) for an appliance covered under the warranty period, no charge is made for service or postage. Please return the product insured, packaged with sufficient protection, and postage and insurance prepaid to the address listed below. Customs duty/brokerage fee, if any, must be paid by the consumer.

Out-of-Warranty Service: A flat rate charge by model is made for out-of-warranty service. Include \$6.00 (U.S.) for return shipping and handling.

Salton/MAXIM cannot assume responsibility for loss or damage during incoming shipment. For your protection, carefully package the product for shipment and insure it with the carrier. Be sure to enclose the following items with your appliance: any accessories related to your problem; your full return address and daytime phone number; a note describing the problem you experienced; a copy of your sales receipt or other proof of purchase to determine warranty status. C.O.D. shipments cannot be accepted.

Return the appliance to:

ATTN: Repair Department, Salton/Maxim Housewares, Inc.
708 South Missouri St. Macon, MO 63552



For more information on Salton/MAXIM products:

visit our website: <http://www.salton-maxim.com> or salton@saltonusa.com