

# **OWNER'S MANUAL**

# **Electric Kettle**

**MODEL No. KE-1**

## **IMPORTANT SAFEGUARDS**

When using electric appliances, basic safety precautions should always be followed including the following:

- 1.** Read all instructions.
- 2.** Do not touch hot surfaces. Use handles or knobs.
- 3.** To protect against fire, electric shock and personal injury, do not immerse cord, plugs, or this kettle in water or other liquid.
- 4.** Close supervision is necessary when any appliance is used by or near children.
- 5.** Unplug from outlet when not in use and before cleaning. Allow to cool before cleaning.
- 6.** Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or adjustment.
- 7.** The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock or personal injury.
- 8.** Do not use outdoors.
- 9.** Do not let cord hang over edge of table or counter, or touch hot surface.
- 10.** Do not place on or near a hot gas or electric burner, or in a heated oven.
- 11.** Do not use appliance for other than intended use.
- 12.** Scalding may occur if the spout is opened during the brewing cycle.
- 13.** Do not overfill or water may boil over.

**SAVE THESE**

## **OPERATING INSTRUCTIONS**

THIS PRODUCT IS FOR HOUSEHOLD USE ONLY.

Be sure kettle is unplugged. Fill your kettle with enough water to cover the element and no more than 2 quarts. Plug cord into the wall outlet. Do not place the kettle on any hot surface.

A short power-supply cord is provided to reduce the hazards resulting from becoming entangled in or tripping over a longer cord. If a longer cord is required, extension cords are available from local hardware stores and may be used if care is exercised in their use. If an extension cord is used (1) the marked electrical rating of the extension cord should be at least as great as the electrical rating of the appliance and (2) the longer cord should be arranged so that it will not drape over the countertop or tabletop where it can be pulled on by children or tripped over accidentally.

# **E INSTRUCTIONS**

## **CLEANING INSTRUCTIONS**

Before the first use boil a kettle of water and throw it away. To clean, disconnect from power supply and wipe with a sponge and warm soapy water. Do not use abrasive cleaners. Do not immerse the kettle in water.

## **TO CLEAN INSIDE OF KETTLE**

Half fill the kettle with approximately 2 pints of water, add 1 fl. oz. of white vinegar to water in the kettle. Plug cord into wall outlet and allow the mixture to boil for about 10 minutes. Remove plug from wall outlet, empty kettle and rinse at least 3 times to remove all dislodged particles and deposits.

## LIMITED WARRANTY

Machines distributed by Salton, Inc. are warranted for one year from date of purchase against defects in workmanship and material. During that period these defects will be repaired or the product will be replaced at Salton's option, without charge. This warranty covers normal consumer usage and does not cover damage which occurs in shipment or failure which results from alteration, accident, misuse, abuse, neglect, installation, commercial use or improper maintenance. This warranty is effective only if the product is purchased and operated in the USA, and does not extend to any units which have been used in violation of written instructions furnished by Salton, Inc., or to units which have been altered or modified without authorization of Salton, Inc., or to damage to products or parts thereof which have had the serial number removed, altered, defaced or rendered illegible.

## To Return for Service

1. Securely package and return the product, PREPAID to:

Salton, Inc.  
Repair Department  
6330 West Touhy Avenue  
Niles, IL 60648

2. Be sure to enclose:
  - a. Your name, address and phone number.
  - b. The date of purchase (or receipt as a gift).
  - c. An explanation of the malfunction or reason for return.

To insure prompt "In-Warranty" service, be sure to include proof of date of purchase.

We recommend you take the necessary precaution of insuring the parcel.

3. **Toll Free** Number: 1-800-233-9054.

**salton**<sup>TM</sup>