

GEORGE FOREMAN®

QUICK START GUIDE | GRILL ASSEMBLY



Align control panel (1) with the probe connections (2) and **push the parts together until the control panel is firmly inserted.**



Slide drip tray under **front** of grill.



Plug cord into outlet.



The **indicator light will turn on** if the control panel is **inserted properly**. If you do not see a light, check if you inserted the control panel all the way.



Allow grill to **preheat** approximately **4½ minutes in the closed position** before grilling.



When grilling temperature is reached, the **green preheat indicator light turns on**.

SUBMERSIBLE™ GRILL SERIES

READ ALL INSTRUCTIONS BEFORE FIRST USE

This Quick Start Guide is not a substitute for the user manual. Before using the appliance, read and understand the warnings and instructions in the user manual. Remove sticker prior to use.

FOR HOUSEHOLD USE ONLY

© 2022 Spectrum Brands, Inc. Middleton, WI 53562 Made in China.

****Product in this box may differ slightly from that pictured.**

® / ™ Spectrum Brands, Inc.
THREE-YEAR LIMITED WARRANTY | See inside for details
T23-9002503-A

GEORGE FOREMAN®

QUICK START GUIDE | GRILL DISASSEMBLY



Wait until the unit is cool. Then **push** the control panel away from the grill with **one or two thumbs** by using the **ridges on top of the control panel** as a grip. Control panel will fully come out and separate from the plates.



Slide the tray out from the base of the grill and **empty** as **necessary** prior to placing in the dishwasher.



Remove control panel before washing. Control panel should not get wet: wipe with a damp cloth and dry thoroughly.



Wash grill top, grill bottom, and drip tray in the **dishwasher or in the sink**. **Drip tray should be placed in the top rack.**

DO NOT use steel wool, scouring pads or abrasive cleaners on any part of the grill.



Thoroughly dry all parts before re-assembling.

- Grill top (1)
- Grill bottom (2)
- Drip tray (3)



Re-assemble by reinserting the control panel (see first page).

Store vertically on back of control panel, loosely wrap the cord around the control panel.

FOR HOUSEHOLD USE ONLY

© 2022 Spectrum Brands, Inc. Middleton, WI 53562 Made in China.

****Product in this box may differ slightly from that pictured.**

® Registered Trademark and TM Trademark of Spectrum Brands, Inc.

THREE-YEAR LIMITED WARRANTY | See inside for details

T23-9002503-A