## INSTRUCTIONS AND WARRANTY

## Model WT-4 Wet Tunes™ The Wet Cassette

Congratulations! You are the proud owner of the Salton Wet Tunes Radio<sup>TM</sup>, to obtain maximum satisfaction and enjoyment, please follow these simple guidelines.

- 1) Do not submerse the wet cassette in water. It is water resistant and contains a water proof speaker. However for maximum life of radio and batteries, do not immerse WT-4 in water.
- 2) Always use alkaline batteries.
- Place Wet Tunes away from shower head to maximize listening abilities. Avoid locations that lie directly in the path of the shower stream.
- 4) Signal reception: Turn on the radio and move it around to various locations and positions on the wall to determine a suitable location which provides good reception.



## WARRANTY

Wet Tunes<sup>TM</sup> is warranted to be free from manufacturing defects for three months from date of purchase. This does not cover damage caused by accident or misuse. If your radio becomes defective during the warranty period, please return the product, prepaid, with proof of purchase and reason for return to the address listed below. Please include six dollars (\$6.00) cheque or money order for postage and handling. Send radio to:

Salton Consumer Repair Service 550 Business Center Drive Mt. Prospect, IL 60056