



GEORGE FOREMAN™

Gas Grills

ASSEMBLY MANUAL & PARTS LIST



GBQ-400 LP
GBQ-400 NG







GBQ-500 LP
GBQ-500 NG

RETAIN FOR FUTURE REFERENCE


George Foreman
MANUFACTURING COMPANY
LIMITED
585 KUMPF DRIVE
WATERLOO, ONTARIO, CANADA
N2V1K3

1


(2)




2





3



4







5



6

(2) 


















7






(2)



(2)







PARTS LIST/LISTE DES PIECES

KEY #	ITEM #	DESCRIPTION	400 LP	400 NG	500 LP	500 NG
1.	10909-T45	CASTING BOTTOM	1	1	.	.
	10909-T60	CASTING BOTTOM	.	.	1	1
2.	10473-T45	CASTING TOP	1	1	.	.
	10473-T60	CASTING TOP	.	.	1	1
3.	10081-GF604	NAMEPLATE	1	1	1	1
4.	10958-K70	TOP CASTING INSERT	1	1	1	1
5.	10571-6	HEAT INDICATOR	1	1	1	1
6.	10240-15	HINGE PIN	2	2	2	2
6A.	S21237	HINGE PIN SPACER	2	2	2	2
7.	S21233	HITCH PIN CLIP	2	2	2	2
8.	10222-T426	FLAV-R-CAST	2	2	.	.
	10222-T626	FLAV-R-CAST	.	.	2	2
9.	10225-T429	GRID-PORCELAIN	2	2	.	.
	10225-T626	GRID-PORCELAIN	.	.	3	3
11.	10225-T451	GRID - WARMING RACK	1	1	.	.
	10225-T628	GRID - WARMING RACK	.	.	1	1
12.	10225-T547	SWING BASKET	1	1	.	.
	10225-T627	SWING BASKET	.	.	1	1
13.	Y-11797	BOLT SWING BASKET	2	2	2	2
15.	10390-T501	BURNER/VENTURI ASSY	1	1	1	1
17.	10342-22	IGNITOR	1	1	1	1
	10342-241	ROTARY IGNITOR	.	.	.	.
	10342-242	ROTARY IGNITOR	.	.	.	.
	10342-243	ROTARY IGNITOR	.	.	.	.
18.	10342-T301	ELECTRODE	2	2	2	2
21.	10440-D50	CONTROL ASSY LP-3V	1	.	.	.
	10440-D51	CONTROL ASSY NG-3V	.	1	.	.
	10440-D66	CONTROL ASSY LP-3V	.	.	1	.
	10440-D67	CONTROL ASSY NG-3V	.	.	.	1
21A.	S10125	HOSE-SIDE BURNER LP	1	.	1	.
	S10126	HOSE-SIDE BURNER NG	.	1	.	1
22.	10114-17	HOSE & REGULATOR LP - QCC1	1	.	1	.
	10111-K47	HOSE NATURAL GAS	1	1	1	1
23.	10472-K37	CONTROL KNOB	2	2	2	2
30.	10086-GF45	DECO PLATE-3V	1	1	1	1
31.	10194-K651	CONTROL COVER	1	1	1	1
35.	10184-K651	SUPPORT-CASTING-LEFT	1	1	1	1
36.	10184-K661	SUPPORT-CASTING-RIGHT	1	1	1	1
37.	10184-K581	SUPPORT-SIDE SHELF-LEFT	2	2	2	2
38.	10184-K591	SUPPORT-SIDE SHELF-RIGHT	2	2	2	2
39.	10958-K831	BRACE-REAR	1	1	1	1
40.	10958-K5891	BASE	1	1	1	1
41.	10958-K851	BRACE-FRONT	1	1	1	1
42.	10958-K89	FRONT PANEL SS	1	1	1	1
43.	10958-K861	SIDE PANEL BLK	2	2	1	1
47.	10184-K19A	TANK RETAINER	2	.	2	.
50.	10711-K561	SHELF-SIDE-RIGHT	1	1	1	1
51.	10711-K563	SHELF-SIDE BURNER	1	1	1	1
56.	10892-8	WHEEL	2	2	2	2
73.	S21420	PUSH NUT	2	2	2	2
74.	Y-6616	BOLT 1/4-20 X 1 1/2	2	2	2	2
75.	10338-145	HANDLE	2	2	2	2
76.	10239-6	WASHER-HANDLE	2	2	2	2
78.	10892-14	CASTOR	2	2	2	2
79.	Y-11545	SCREW - 1/4-20 X 1 3/8	4	4	4	4

PARTS LIST/LISTE DES PIECES

<u>KEY #</u>	<u>ITEM #</u>	<u>DESCRIPTION</u>	<u>400 LP</u>	<u>400 NG</u>	<u>500 LP</u>	<u>500 NG</u>
80.	Y-11549	SCREW- 1/4-20 X 1 7/8	10	10	10	10
82.	Y-12860	SCREW 1/4-20 X 1	18	18	18	18
83.	S21014	BOLT- 1/4-20 X 1/4	6	6	6	6
84.	S15178	AXEL	1	1	1	1
87.	Y-11793	NUT- 1/4-20	16	16	16	16
88.	Y-11598	NUT-WING - 1/4-20	2	2	2	2
90.	Y-12286	LAG-BOLT - 5-16 X 4	4	4	4	4
98.	S21123	SCREW - 8 X 1/4	34	34	34	34
99.	Y-12646	SCREW - SHOULDER 8 X 1/4	2	2	2	2
104	Y-12835	SCREW - 6-32 X 1/4	4	4	4	4
105.	Y-29307	NUT - 10-24	5	5	5	5
108.	PB20-60	LID HANDLE	1	1	1	1
109.	S21136	SCREW - 8-32 X 3/8	2	2	2	2
110.	10225-T10	GRID	1	1	1	1
111.	10390-T10	SIDE BURNER	1	1	1	1
113.	10342-T08	ELECTRODE - SIDE BURNER	1	1	1	1
114.	10393-K40	COVER-SIDE BURNER	1	1	1	1
115.	Y-29305	SCREW - 10-24 X 3/8	6	6	6	6
117.	10393-K50	SHELF-SIDE BURNER	1	1	1	1
118.	10393-T221	SHEILD-SIDE BURNER	1	1	1	1
121.	10184-K613	CASTOR SUPPORT	1	1	1	1
123.	S15115	GREASE PAN - DISPOSABLE	2	2	2	2

