

1 EASY-TO-USE CONTROLS
3 knobs for simple temperature, function, and time settings including integrated toast timer.

2 30-MINUTE TIMER
The 30-minute precision timer features stay-on function for long baking tasks.

3 CONVENIENT COMPACT SIZE
Easily fit a 9" pizza, four slices of bread, or a variety of other snacks and meals.

AIR FRY TECHNOLOGY

Deep fried taste without the fat™! This innovative cooking method surrounds food with high intensity hot air to bake, brown, and crisp your favorite foods using little to no oil.




5 COOKING FUNCTIONS

Choose from five available cooking methods: bake, broil, toast, keep warm, and air fry.

EVENTOAST TECHNOLOGY™

Delivers delicious, evenly browned toast with a unique heat diffuser that distributes powerful heat combined with infrared energy throughout the entire oven interior.



Easy-view Glass Door

Keep an eye on food during cooking. The durable glass window gives you a clear view of food throughout the cooking process.




Internal Crumb Tray

The internal crumb tray makes it easy to remove crumbs before they burn in the bottom of the oven.



Air Fry Technology

Deep fried taste without the fat! This innovative cooking method surrounds food with high intensity hot air to bake, brown, and crisp your favorite foods using little to no oil.



5 Cooking Functions

Choose from five available cooking methods: bake, broil, toast, keep warm, and air fry.



Convenient Compact Size

Easily fit a 9" pizza, four slices of bread, or a variety of other snacks and meals.




30-minute Timer

The 30-minute precision timer features stay-on function for long baking tasks.



3 Knob Control Panel

Quickly set the function, temperature and time using the easy control knobs.



EvenToast Technology™



Easy-view Glass Door



Accessories Included




CRISP N' BAKE™ AIR FRY TECHNOLOGY

Deep fried taste without the fat™! Now with Crisp N' Bake™ Air Fry Technology, this 4-slice air fryer toaster oven uses high intensity hot air to bake, brown, and crisp your favorite fried foods with little to no oil.

BLACK+DECKER® Crisp 'N Bake™ 4-Slice Air Fry Toaster Oven, TO1747SSG

Deep fried taste without the fat™! Now with Crisp N' Bake™ Air Fry Technology, this 4-slice air fryer toaster oven uses high intensity hot air to bake, brown, and crisp your favorite fried foods with little to no oil. Three control knobs simplify cooking, letting you set the 30-minute timer and choose from five cooking functions: Air Fry, Bake, Broil, Toast, and Keep Warm. On the toasting function, EvenToast Technology™ evenly distributes heat and infrared energy for consistent doneness. Countertop cooking is simple and convenient using the 30-minute timer and a full menu of preset functions. Plus, the toaster oven is perfect for making your favorite frozen snacks: chicken nuggets, mozzarella sticks, egg rolls, or whatever else you're craving.





EvenToast Technology™

Delivers delicious, evenly browned toast with a unique heat diffuser that distributes powerful heat combined with infrared energy throughout the entire oven interior.



Easy-view Glass Door

Keep an eye on food during cooking. The durable glass window gives you a clear view of food throughout the cooking process.



Accessories Included

Don't worry about finding pans to fit in the oven. The included air fry basket, bake/broil rack and pan fit perfectly, making it easy to insert and remove food.



Air Fry Technology



5 Cooking Functions



Convenient Compact Size



30-minute Timer



Accessories Included



