


RELAXOR[®]



CRYSTAL BALL

Sound & Aroma System

OWNER'S MANUAL &
OPERATING INSTRUCTIONS

Model ST8CB

LIGHT THERAPY[™]

IMPORTANT SAFEGUARDS

Please read carefully before using your CRYSTAL BALL Sound & Aroma System.

- 1. Unplug unit before cleaning.*
- 2. Keep Aromatherapy Beads out of the reach of children.*
- 3. To protect against risk of electrical shock, do not submerge unit or allow AC cord to come in contact with water or other liquids.*
- 4. Close supervision is necessary when any appliance is used by or near children.*
- 5. Use this appliance only for it's intended use as described in this manual.*
- 6. Do not operate appliance with a damaged cord or plug or after the appliance malfunctions or has been dropped or damaged in any manner. Refer to the warranty section of this manual.*
- 7. The use of attachments not recommended or sold by the manufacturer may cause fire, shock or injury.*
- 8. Do not use outdoors.*
- 9. Do not let cord hang over the edge of a table or counter or touch hot surfaces.*
- 10. Never block the air openings of the appliance or place it on a soft surface such as a bed, pillow or couch, where the air openings may be blocked. Keep the openings free of lint or dust.*
- 11. Do not use Aromatherapy Beads in the presence of babies under six (6) months old.*
- 12. Do not use Aromatherapy Beads in the presence of pregnant women or persons with breathing difficulties without first consulting a physician.*
- 13. Do not take Aromatherapy Beads internally. In case of accidental ingestion, contact a physician immediately.*
- 14. Do not allow Aromatherapy Beads to come into contact with eyes. If this occurs, flush out eyes with clean water, and contact a physician immediately.*
- 15. Some Aromatherapy Beads may cause an allergic reaction in certain people. If this occurs you should immediately stop using them. If symptoms persist consult a physician.*

**SAVE THESE INSTRUCTIONS
FOR HOUSEHOLD USE ONLY**

The RELAXOR® CRYSTAL BALL Sound & Aroma System offers the ultimate in environment enhancing relaxation: Sound, Aromatherapy and Light in a single, portable, easy-to-operate unit. Relax with the touch of a button and enjoy any one of seven sounds of nature: heartbeat, ocean, fountain, bird songs, summer night, white noise and spring rain. Press the Light Button to turn on any one of seven colors of light: white, green, red, yellow, dark blue, light blue and purple. Press the Aroma Button to add the sensuously soothing element of fragrance to the atmosphere. There are two Fragrance selections included with this unit — one to revitalize and refresh, one to relax and relieve stress. Enjoy Sound, Fragrance and Light together or individually as desired.

NOTES ON AROMATHERAPY BEADS

- Keep Aromatherapy Beads out of the reach of children.
- Do not take Aromatherapy Beads internally. In case of accidental ingestion, contact a physician immediately.
- Take care when handling Aromatherapy Beads.
- Do not allow Aromatherapy Beads to come into contact with eyes. If this occurs, flush out eyes with plenty of clean, fresh water and call a physician.
- Only use Aromatherapy Beads included in this package, or sold by the manufacturer of this appliance. Other Aromatherapy Beads may not be safe for use with this appliance.
- Some Aromatherapy Beads may cause an allergic reaction in certain people. If this occurs you should stop using the Beads, and, if symptoms persist, consult a physician.
- Do not use Aromatherapy Beads in the presence of babies under six (6) months old.
- Do not use Aromatherapy Beads in the presence of pregnant women or persons with breathing difficulties without first consulting a physician.

CAUTION: Aromatherapy Beads are for external use only.


Do not ingest. If swallowed, consult a physician.

KEEP AWAY FROM CHILDREN

OPERATING INSTRUCTIONS

BATTERY INSTALLATION

Remove Battery Compartment Cover on bottom of unit by pressing tab toward Cover and lifting Cover off. Install 4 "AA" batteries in Compartment. Refer to diagram inside Battery Compartment for correct battery replacement. Replace Cover.



TO USE WITH ADAPTER

Insert Adapter Jack into back of unit, and plug Adapter (P/N 50231) into any 120V AC electrical outlet (ordinary household current).

NOTE: If unit contains batteries, they should be removed before operating with the Adapter. Do not use any Adapter other than the one supplied with this unit.

Press the Power Button once to turn the unit ON. When the Power Button is pressed the Light will activate, showing the default color, white. Pressing the Power Button a second time will shut the unit OFF. Unit must be turned ON before its Light, Aroma and Sound features can be used.


OPERATING INSTRUCTIONS (Continued.)

LIGHT

When the unit is activated the Light will come on. Pressing the Light Button once will turn the Light OFF. Pressing the Light Button a second time will activate the colored lights. There are seven different colors to choose from: blue, green, light blue, red, purple, yellow and white. Continue pressing the Light Button to switch from one color to the next.

SOUND

To activate the Sound feature select the calming sound you would like to hear: heart beat, ocean, birds song, summer night, white noise or spring rain. Press that Button once, pressing the Button a second time will shut the Sound OFF. If the Light is activated it will follow the frequency of the Sound selected. To change the volume, adjust the Volume Control rotary dial on the side of the unit.




OPERATING INSTRUCTIONS (Continued.)

AROMA

To fill the Fragrance Compartment remove the Crystal Ball and measure a capful of Beads (slightly less than a tablespoon) and pour them into the Bead Chamber. Then, press the Aroma Button once to activate the Fragrance. Press the Aroma Button a second time to turn the Fragrance OFF.

If preferred, you may add more Beads. The more Beads used, the stronger the Fragrance will be.



NOTE: After using, be sure to return Beads to their Vial for storage, closing tightly to preserve the scent.

OPERATING INSTRUCTIONS (Continued.)

TIMER

This unit is equipped with a Timer feature that allows the Fragrance and Sound to shut OFF automatically, after 15, 30 or 45 minutes. Two LED Indicators located next to the Timer Button illuminate to denote amount of time remaining. To operate:

- 1. To select the 15 Minute Timer, press the Timer Button once. The upper LED Light will flash, indicating that the 15 Minute Timer has been selected.*
- 2. To select the 30 Minute Timer, press the Timer Button a second time. This will cause the lower LED Light to flash, indicating that the 30 Minute Timer has been selected.*
- 3. To select the 45 Minute Timer, press the Timer Button a third time. This will cause both LED Lights to flash, indicating that the 45 Minute Timer has been selected.*

If there is between 30-45 minutes of time remaining, both Indicators will flash, when operating time remaining is between 15-30 minutes the lower LED Indicator only will flash and when there is less than 15 minutes of operating time remaining only the upper LED Light will flash.

USER MAINTENANCE INSTRUCTIONS

This appliance requires little maintenance and contains no user serviceable parts. Do not try to fix it yourself. Refer it to qualified service personnel if servicing is needed.

TO CLEAN

Wipe unit with a soft, slightly damp cloth or sponge. Never use scouring pads or harsh, abrasive cleaners. Do not immerse unit in water or any other liquid. Never allow water or any liquid to come into contact with the unit.

TO STORE

Store unit in its own box or in a clean, dry place. For long-term storage, remove batteries before storing. Fragrance Vials may be kept with unit; be sure Covers are tightly closed before putting them away.