

Model No. MMS14T

# Travel *essentials*<sup>™</sup>

## TRAVEL IRON<sup>™</sup>



**salton**<sup>®</sup>

The Archives of  
Milton H. Greene, L.L.C.

*Marilyn Monroe*™





Marilyn Monroe stands as one of the 20th century's most enduring images, an icon reborn, it seems, with each new generation. The man who best understood and captured - some say invented - this phenomenon was her friend and partner, the late Milton H. Greene.

It was Greene's unique personal friendship and business relationship with Marilyn Monroe that allowed the extraordinary photographs, recording her moods, beauty, talent and spirit, for which he is most widely remembered. The Monroe collection contains more than 2,000 never before seen photographs of the screen legend.

Greene's remarkable portraits of our most beloved artists, musicians, and personalities are legendary. Some of his subjects are Marlene Dietrich, Frank Sinatra, Judy Garland, Sammy Davis Jr., Ava Gardner, Cary Grant, Bette Davis, Tony Curtis, Paul Newman, Steve McQueen, Audrey Hepburn, Gene Kelly and Sophia Loren.

In a return to an era of lost elegance, The Archives, headed by Milton's eldest son Joshua, is preserving the vision and timeless works of the celebrated photographer. The Archives is dedicated to the restoration, license and sale of an unprecedented wealth of fine photography for use in traditional and interactive marketing, mass media, merchandising, exhibition and private collections.

The Archives, working in conjunction with Salton®, specifically restored and made available the Monroe images used in the packaging of these products.

We invite you to visit our website at **[www.archivesmhg.com](http://www.archivesmhg.com)** or feel free to contact us.

The Archives of  
Milton H. Greene, LLC  
278 Maple Street Suite E  
Florence, OR 97439  
541-997-4970 fax: 541-997-5795

# IMPORTANT SAFEGUARDS

1. Read all instructions before using.
2. Use the Iron for intended use only.
3. To protect against a risk of electrical shock, do not immerse the Iron in water or other liquids.
4. The Iron should always be turned to MIN before plugging in or unplugging from the wall socket. Never yank the cord to disconnect from the wall socket; instead, grasp the plug and pull to disconnect.
5. Do not allow cord to touch hot surfaces. Let the Iron cool completely before putting away, then loop cord loosely around the Iron when storing.
6. Always disconnect the Iron from the electrical outlet when filling with water or emptying and when not in use.
7. Do not operate Iron with a damaged cord/plug or if the Iron has been dropped or damaged. To avoid the risk of electrical shock, do not disassemble the Iron, take it to a qualified serviceman for examination and repair. Incorrect re-assembly can cause a risk of electrical shock when the Iron is used.
8. Close supervision is necessary for any appliance being used by our near children. Do not leave the Iron unattended while connected or on an ironing board.
9. Burns can occur from touching hot metal parts, hot water or steam. Use caution when you turn a steam iron upside down - there may be hot water in the reservoir.

# **IMPORTANT SAFEGUARDS**

## **(cont.)**

- 10.** To avoid a circuit overload, do not operate another high wattage appliance on the same circuit.
- 11.** If an extension cord is absolutely necessary, a 10-ampere cord should be used. Cords rated for less amperage may overheat. Care should be taken to arrange the cord so that it cannot be pulled or tripped over.
- 12.** Take care: if you are leaving the appliance momentarily, always switch it off, remove the plug from the wall socket and stand the Iron on its base.
- 13.** This Travel Iron is not intended for regular use.
- 14.** Be sure Dual Voltage Selector is in correct voltage position before operating. Before plugging in the Iron, read the information about dual voltage operation contained in the "Instructions for Use" section of this manual.

## **POLARIZED PLUG**


This appliance has a polarized plug (one blade is wider than the other). As a safety feature, this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.

## **SAVE THESE INSTRUCTIONS**


# GETTING TO KNOW YOUR Salton *Travel* Iron

Before attempting to use your Salton Travel Iron, you should become familiar with all of the parts. Read all of the instructions and safeguards carefully.

Identify all parts of your Salton Travel Iron according to the drawing below so that you have no doubts when reading the instructions that follow.



(Fig. 1)



(Fig. 2)

# INSTRUCTIONS FOR USE

Before using the Travel Iron, you must first set the Dual Voltage Switch to either 120V or 240V. If you are traveling in the U.S., you will use the 120V setting. The need for 240V depends on where you travel.

When using the Travel Iron for the first time, test on an old piece of fabric to ensure the Soleplate and Water Tank are completely clean.


The Iron may smoke slightly when switched on for the first time. This is normal and will soon cease.

## 1. Move up the Handle.

Press the Handle Lock Button down, and the Handle will automatically rise to the upright position (Fig. 1)

## 2. Fill the Water Tank.

- A. Place thumb and fore-finger on upper and lower side at the end of the Handle, pull the Water Tank Button backwards by thumb to detach the Tank from the Handle. (Fig. 3)




(Fig. 3)

# INSTRUCTIONS FOR USE

## (cont.)

- B.** Lift the cap from the fill hole on the Tank and fill with tap water.  
(Fig. 4)



(Fig. 4)

- C.** Replace the cap, ensuring it is fastened securely, and lock the Water Tank back into place by using the Water Tank Button.
- 3. Connect plug to an electrical outlet.**  
Stand the Iron up on its end, turn the Temperature Adjustment Dial to MIN and connect the plug to the electrical outlet.






# INSTRUCTIONS FOR USE

## (cont.)

### 4. Set Temperature Adjustment Dial.

Set the Temperature Adjustment Dial to the desired setting.

See chart below for suggested settings.

| Fabric   | Temperature Dial Position   |
|--|---|
| Nylon, Polypropylene<br>Acrylics, Polyurethane |  |
| Polyester, Mixtures Wool                       |  |
| Cotton, Linen, Rayon<br>Mixtures               |  |

### 5. Starting Operation.

The Iron will reach the appropriate temperature after about 5 minutes. Test the Iron on the cloth, then iron as usual. The automatic thermostat will maintain the correct temperature throughout use.

### 6. Blast of Steam.

For particularly stubborn creases, the Blast of Steam function can be used if the Temperature Adjustment Dial is set at the highest setting. Wait for the Iron to reach the correct temperature, lift the Iron slightly above the surface of the fabric and press the Blast of Steam Button firmly, and then release.

# STORAGE

After use, turn the Temperature Adjustment Dial to MIN position. Disconnect the Iron from the electrical outlet and empty the Water Tank. Stand the Iron upright to allow it to cool. After cooling it fully, press the Release Lock Button to move the Handle into the original position. Store in a cool, dry place, in the Carrying Pouch provided, or in its original packaging. Do not wrap the cord tightly around the Iron as this could cause it to fray.



# CARE AND CLEANING

Before cleaning the Iron, make sure that it is unplugged from the wall and that it has completely cooled.

Deposits on the Soleplate may be removed with a cloth soaked in a vinegar/water solution. Do not use abrasive cleaners or utensils.

The casing may be wiped with a damp cloth and then polished with a dry one.

This Iron is equipped with a safety automatic shut-off feature. In the unlikely event of the thermostat failing, the automatic shut-off will be activated to prevent the Iron from overheating. The Iron should then be taken to a qualified electrician for examination and repair.

# ONE YEAR LIMITED WARRANTY

This Salton Product warranty extends to the original consumer of the product.

**Warranty Duration:** This product is warranted to the original consumer purchaser for a period of one (1) year from the original purchase date.

**Warranty Coverage:** This product is warranted against defective materials or workmanship. This warranty is void if the product has been damaged by accident, in shipment, unreasonable use, misuse, neglect, improper service, commercial use, repairs by unauthorized personnel or other causes not arising out of defects in materials or workmanship. This warranty is effective only if the product is purchased and operated in the USA, and does not extend to any units which have been used in violations of written instructions furnished by Salton, Inc., or to units that have been altered or modified or to damage to products or parts thereof which have had the serial number removed, altered, defaced or rendered illegible.

**Warranty Disclaimers:** This warranty is in lieu of all warranties expressed or implied and no representative or person is authorized to assume for Salton, Inc. any other liability in connection with the sale of our products. There shall be no claims for defects or failure of performance or product failure under any theory of tort, contract, or commercial law including, but not limited to, negligence, gross negligence, strict liability, breach of warranty and breach of contract.

**Warranty Performance:** During the above one-year limited warranty period, a product with a defect will be either repaired or replaced with a reconditioned comparable model (at Salton, Inc.'s option), when the product is returned to the Salton, Inc. facility. The repaired or replacement product will be in warranty for the balance of the one year warranty period and an additional one month period. No charge will be made for such repair or replacement.

## Service and Repair

Should the appliance malfunction, you should first call toll-free 1-800-233-9054 between the hours of 9:00am and 5:00pm Central Standard Time and ask for Customer Service stating that you are a consumer with a problem.

**In-Warranty Service:** For an appliance covered under the warranty period, no charge is made for service or postage. Call for a pre-paid return mailing label (U.S. customers only).

**Out-of-Warranty Service:** A flat rate charge by model is made for out-of-warranty service. Include \$8.00 for return shipping and handling. Salton, Inc. cannot assume responsibility for loss or damage during incoming shipment. For your protection, carefully package the product for shipment and insure it with the carrier. Be sure to enclose the following items with your appliance: any accessories related to your problem; your full return address and daytime phone number; a note describing the problem you experienced; a copy of your sales receipt or other proof of purchase to determine warranty status. C.O.D. shipments cannot be accepted.

ATTN: Repair Department, Salton, Inc.  
708 South Missouri St.  
Macon, Macon 33552



For more information on Salton/Maxim products:  
visit our website: <http://www.salton-maxim.com>  
or email us at: [salton@saltonusa.com](mailto:salton@saltonusa.com)