



PARTS IDENTIFICATION



Top shelf - 1 piece



Middle shelf - 3 pieces



Bottom shelf - 1 piece



left leg - 2 pieces



Right leg - 2 pieces



1 inch screw - 5 pieces
(1 spare)



wood dowel - 1 piece




1 1/4 inch screw - 11 pieces
(1 spare)



Allen wrench - 1 piece

PHOTEX LADDER ASSEMBLY INSTRUCTION



Step 1:


Lay all components on floor as illustrated

The shelves should be positioned so that the side with the deepest channels faces downward. The shallow channels should face upward

Wood dowel shelf support is to be positioned in the bottom of the lowest shelf

Step 2:

Assemble each leg as illustrated using the allen wrench (provided).



Step 3:

Assemble the shelves starting with the top shelf.

Step 4:

Insert bottom shelf support (wood dowel).

Step 5:

Carefully lift the assembled ladder unit and lean it against a wall. The top two shelves should touch the wall.

Step 6:

To insert photo frames: insert the top of the frame into the groove on the bottom of the shelf. Swing the bottom of the frame into the groove on the lower shelf.

