

OWNER'S MANUAL

Model No. LM8

THE LEMONADER™



salton®

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed, including the following:

1. Read all instructions.
2. Do not touch hot surfaces. Use handles or knobs.
3. To protect against fire, electric shock and injury to persons, do not immerse cord, plugs, or appliance in water or other liquid.
4. Close supervision is necessary when any appliance is used by or near children.
5. Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
6. Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner. Contact consumer service for return authorization.
7. The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or injury to persons.
8. Do not use outdoors.
9. Do not let cord hang over edge of table or counter, or touch hot surfaces.
10. Do not place on or near a hot gas or electric burner, or in a heated oven.
11. To disconnect, press the ON/OFF switch to turn the power indicator light OFF, then grasp plug and remove from wall outlet.
12. Do not use appliance for other than intended use.
13. Be certain lids are securely in place before operating appliance.
14. Scalding may occur if the lid is removed during the brewing cycle.
15. Avoid contacting moving parts.

SAVE THESE INSTRUCTIONS

THIS APPLIANCE IS FOR HOUSEHOLD USE ONLY

Additional Important Safeguards

1. ***CAUTION: This appliance generates heat and escaping steam during use. Proper precautions must be taken to prevent the risk of burns, fires or other damage to persons or property.***
2. All users of this appliance must read and understand this Owner's Manual before operating or cleaning this appliance.
3. The cord to this appliance should be plugged into a 120V AC electrical outlet only.
4. When using this appliance, provide adequate air space above and on all sides for air circulation. Do not allow this appliance to touch curtains, wall coverings, clothing, dish towels or other flammable materials during use.
5. Do not leave this appliance unattended during use.
6. This appliance generates steam—do not operate in open position.
7. The unit must be left to cool down for approximately 15 minutes before adding more water.
8. Always use fresh, cool water in your Lemonader™. Warm water or other liquids may cause damage to the appliance.
9. If this appliance begins to malfunction during use, immediately unplug cord from outlet. Do not use or attempt to repair the malfunctioning appliance.

Use ONLY cold water in the Water Reservoir. Do not use any other liquid such as juice, with exception to Periodic Descaling in "User Maintenance Instructions".

Polarized Plug


This appliance has a **polarized plug** (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit into a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to modify the plug in any way.

Short Cord Instructions

A short power-supply cord is provided to reduce the risk resulting from becoming entangled in or tripping over a longer cord. Longer detachable power-supply cords or extension cords are available and may be used if care is exercised in their use.

If a longer detachable power-supply cord or extension cord is used, (1) the marked electrical rating of the extension cord should be at least as great as the electrical rating of the appliance, and (2) the longer cord should be arranged so that it will not drape over the counter top or table top where it can be pulled on by children or tripped over unintentionally.

Getting To Know Your LM8



- | | |
|----------------------------------|---------------------------------------|
| 1. Base | 8. Juice Extractor Cover (P/N 30804) |
| 2. ON/OFF Button | 9. Juice Extractor (P/N 30805) |
| 3. Power On Indicator | 10. Juice Chamber |
| 4. Pitcher (P/N 30808) | 11. Juice/Sugar Container (P/N 30807) |
| 5. Water Reservoir | 12. Cord |
| 6. Sugar Chamber | |
| 7. Sugar Chamber Lid (P/N 30806) | |

Introduction

Choose old fashioned lemonade or a subtle blend of crisp and refreshing fruit drinks with the Salton® 2 1/2 quart Lemonader™. Select from any one of the numerous recipes, follow the easy steps and you will have an ice cold pitcher of the most enjoyable and delicious lemonade you thought possible. Juicing lemons and other citrus fruit is a breeze with the bi-directional juice extractor. This unique appliance will make many summer seasons a season to remember and with the dishwasher safe containers, it makes clean-up a breeze.

Before First Use

Before operating the Lemonader™ for the first time, fill the Water Reservoir with water only, and allow the full quantity to flow through the appliance to remove any possible dust or foreign matter. After running the water through the appliance, wash the Juice Extractor, the Juice/Sugar chamber, and the Pitcher in soapy water. Rinse and dry thoroughly.

Basic Ingredients

32 ounces cold water (16 oz each, about 946 ml)
1/2 - 1 cup sugar (230g)
4 - 6 lemons, cut in half
ice cubes

Operating Instructions

Includes Basic Lemonade Recipe

1. Prepare the lemons. Wash and cut 4-6 lemons in half. Make sure the unit is unplugged and the power indicator light is OFF. Lift off the Juice Extractor Cover, the Juice Extractor and the Juice/Sugar Container.

2. Fill the Pitcher with cold water to the "WATER" line (about 16 ounces) and pour it into the Water Reservoir. See Figure 1.

3. Place the Juice/Sugar Container on top of the Water Reservoir and press down until it is fully seated.

4. Refill the Pitcher with cold water to the "WATER" line and add ice cubes up to the "ICE" line. Close the Pitcher Lid and place it onto the Base.

5. Pour up to one cup sugar into the Sugar Chamber next to the Juice Chamber. See Figure 2. Close the Sugar Chamber Lid.

6. Place the Juice Extractor on the Juice Extractor Drive.

7. Plug the Unit into a 120V AC outlet and press the ON/OFF Switch. The power indicator light will turn ON. Once the water is heated it will travel up into the Sugar Chamber to mix with the sugar.

WARNING: Always keep the Lid closed when the unit is mixing the sugar into syrup. There will be steam coming from the gap between the Juice/Sugar Container and the Lid.

8. While the water is brewing, ream the lemon halves on the Juice Extractor by pressing down on the lemon rind.

9. The brewing cycle may be paused or interrupted by pressing the ON/OFF Switch. The power indicator light will turn OFF. To resume brewing and the lemonade making process, press the ON/OFF Switch and the power indicator light will turn ON. **NOTE:** The pause/interrupt feature should not be used for more than 5 minutes. Pausing the unit longer than 5 minutes may affect the quality of the syrup making process.

10. Wait until the brewing cycle is complete. When the brewing cycle is complete the unit will turn off automatically. The power indicator light will turn OFF.

11. Remove the Pitcher from the Base and enjoy the lemonade.




Figure 1




Figure 2

User Maintenance Instructions

The Lemonader™ requires little maintenance. It contains no user-serviceable parts.

CAUTION: Always unplug Lemonader™ and allow to cool thoroughly before cleaning. Never immerse Lemonader™ Base, Cord, or Plug in water or other liquids.

1. Before cleaning, unplug the Lemonader™ from the wall outlet and allow to cool.
2. Remove the Pitcher, Juice Extractor Cover, Juice Extractor, and Juice/Sugar chamber wash in warm, soapy water. Rinse and dry thoroughly. These parts are also dishwasher safe.
3. Do not use steel wool, scouring pads, or abrasive cleaners on any part of the Lemonader™.
4. Wipe all exterior surfaces with a soft cloth dampened with water.
5. **DO NOT IMMERSE BASE UNIT IN WATER OR OTHER LIQUID.**
6. Any servicing requiring disassembly other than the above cleaning must be performed by Salton Inc. Repair Center (see Warranty Page for further instructions).

Periodic Descaling

Since mineral deposits from tap water can form a coating in the Lemonader™, causing slower brewing times and possibly affecting the flavor, we recommend the following cleaning:

1. Pour 8 ounces of vinegar and 8 ounces of cold water into the Water Reservoir.
2. Place the Juice/Sugar Container on top of the Water Reservoir and press down until fully seated.
3. Place the Pitcher onto the Base.
4. Without adding any ingredients, switch the unit ON and let the water run throughout the unit into the Pitcher. Discard water after it has run through the machine.
5. Allow the unit to cool for 15 minutes and run 16 ounces of fresh cold water through the brewing cycle. Discard the brewed water.
6. Rinse all parts thoroughly.

NOTE:

- To maintain the performance of your Lemonader™, it is recommended to periodically flush the unit before storing. Flushing the unit with water will wash away remaining sugar. Wait 15 minutes after you have completed making lemonade, then pour cold water in the Water Reservoir and press the ON/OFF switch to let the water heat and flush through the system.
- Do not use any chemicals or abrasive cleaners.
- Never immerse the appliance, cord or plug in water or any other liquid.
- During the descaling process, black flakes (burnt sugar) may flush out. This is part of the descaling process.

Storing Instructions

Unplug the unit from the wall outlet and clean all parts. Be sure all parts are dry before storing. Place the Juice Extractor Cover over the Juice Extractor when the Lemonader™ is not in use to help keep out dust. Store the Lemonader™ in its box or in a clean, dry place. Never store it while it is hot, wet or still plugged in. Never wrap Power Cord around the appliance.

Recipes

Fresh Homemade Lemonade

2 cups	water
1/2 - 1 cup	sugar
2 cups	water
	ice
4 - 6	fresh lemons

With the Lemonader™ unplugged, fill the pitcher with water to the water line (2 cups total). Pour the water into the water reservoir. Fill the sugar chamber with the sugar, spreading evenly. Refill the pitcher with the remaining water. Add ice to the ice line as indicated on the pitcher. Turn on the Lemonader™ and juice the lemons. When the unit shuts off, gently stir the juice and serve.

Pink Lemonade Swizzle

2 cups	water
1/2 - 1 cup	sugar
1 cup	cranberry juice cocktail
1 cup	water
	ice
4 - 6	fresh lemons

With the Lemonader™ unplugged, fill the pitcher with water to the water line (2 cups total). Pour the water into the water reservoir. Fill the sugar chamber with the sugar, spreading evenly. Refill the pitcher with the cranberry juice cocktail and remaining water. Add ice to the ice line as indicated on the pitcher. Turn on the Lemonader™ and juice the lemons. When the unit shuts off, gently stir the juice and serve.

Recipes (Cont.)

Summertime Limeade

2 cups water
1/2 - 1 cup sugar
2 cups water
 ice
8 - 12 fresh limes

With the Lemonader™ unplugged, fill the pitcher with water to the water line (2 cups total). Pour the water into the water reservoir. Fill the sugar chamber with the sugar, spreading evenly. Refill the pitcher with the remaining water. Add ice to the ice line as indicated on the pitcher. Turn on the Lemonader™ and juice the limes. When the unit shuts off, gently stir the juice and serve.

Cranberry Sunrise Juice

2 cups water
1/2 cup sugar
1 - 11.5 oz can cranberry juice cocktail concentrate
1 1/2 cups water
 ice
2 fresh oranges
2 fresh lemons
1 fresh lime (optional)

With the Lemonader™ unplugged, fill the pitcher with water to the water line (2 cups total). Pour the water into the water reservoir. Fill the sugar chamber with the sugar, spreading evenly. Refill the pitcher with the cranberry juice concentrate and the remaining water. Add ice to the ice line as indicated on the pitcher. Turn on the Lemonader™ and juice the oranges, lemons and lime. When the unit shuts off, gently stir the juice and serve.

Raspberry Lemon Razzle

2 cups	water
1/2 cup	sugar
1-12 oz.	can frozen raspberry juice concentrate
1 1/2 cups	water
	ice
2 - 4	fresh lemons

With the Lemonader™ unplugged, fill the pitcher with water to the water line (2 cups total). Pour the water into the water reservoir. Fill the sugar chamber with the sugar, spreading evenly. Refill the pitcher with the raspberry juice concentrate and remaining water. Add ice to the ice line as indicated on the pitcher. Turn on the Lemonader™ and juice the lemons. When the unit shuts off, gently stir the juice and serve.

Lemon-Lime Time

2 cups	water
1 cup	sugar
2 cups	water
	ice
2 - 4	fresh lemons
4 - 6	fresh limes

With the Lemonader™ unplugged, fill the pitcher with water to the water line (2 cups total). Pour the water into the water reservoir. Fill the sugar chamber with the sugar, spreading evenly. Refill the pitcher with the remaining water. Add ice to the ice line as indicated on the pitcher. Turn on the Lemonader™ and juice the lemons and limes. When the unit shuts off, gently stir the juice and serve.

Recipes (Cont.)

Citrus Party Punch

2 cups	water
1/4 cup	sugar
3/4 cup	fruit punch liquid concentrate
1 1/4 cups	water
	ice
2 - 4	fresh oranges
2	fresh lemons
1	fresh lime

With the Lemonader™ unplugged, fill the pitcher with water to the water line (2 cups total). Pour the water into the water reservoir. Fill the sugar chamber with the sugar, spreading evenly. Refill the pitcher with the fruit punch concentrate and remaining water. Add ice to the ice line as indicated on the pitcher. Turn on the Lemonader™ and juice the oranges, lemons and lime. When the unit shuts off, gently stir the juice and serve.

Hawaiian Breeze

2 cups	water
1/4 cup	sugar
1 - 12 oz.	can frozen pineapple juice concentrate
1 1/2 cups	water
	ice
2 - 4	fresh oranges
1	fresh lemon

With the Lemonader™ unplugged, fill the pitcher with water to the water line (2 cups total). Pour the water into the water reservoir. Fill the sugar chamber with the sugar, spreading evenly. Refill the pitcher with the pineapple juice concentrate and remaining water. Add ice to the ice line as indicated on the pitcher. Turn on the Lemonader™ and juice the oranges and lemon. When the unit shuts off, gently stir the juice and serve.

Golden Glow Squeeze

2 cups	water
1/2 cup	sugar
2 cups	water
	ice
1	fresh ruby grapefruit
6 - 8	fresh tangerines
2 - 3	fresh lemons

With the Lemonader™ unplugged, fill the pitcher with water to the water line (2 cups total). Pour the water into the water reservoir. Fill the sugar chamber with the sugar, spreading evenly. Refill the pitcher with the remaining water. Add ice to the ice line as indicated on the pitcher. Turn on the Lemonader™ and juice the grapefruit, tangerines and lemons. When the unit shuts off, gently stir the juice and serve.

Tea-Party-Perfect Lemon Tea

2 cups	water
3/4 cup	instant, pre-sweetened, decaffeinated tea
2 cups	water
	ice
2	fresh lemons

With the Lemonader™ unplugged, fill the pitcher with water to the water line (2 cups total). Pour the water into the water reservoir. Fill the sugar chamber with the instant tea, spreading evenly. Refill the pitcher with the remaining water. Add ice to the ice line as indicated on the pitcher. Turn on the Lemonader™ and juice the lemons. When the unit shuts off, gently stir the tea and serve.

Recipes (Cont.)

Orange-Lemon-Lime Blast

2 cups	water
3/4 cup	sugar
1-12 oz.	can frozen orange juice concentrate
1 1/2 cups	water
	ice
2 - 4	fresh lemons
2 - 4	fresh limes
sprigs	fresh mint

With the Lemonader™ unplugged, fill the pitcher with water to the water line (2 cups total). Pour the water into the water reservoir. Fill the sugar chamber with the sugar, spreading evenly. Refill the pitcher with the orange juice concentrate and remaining water. Add ice to the ice line as indicated on the pitcher. Turn on the Lemonader™ and juice the lemons and limes. When the unit shuts off, gently stir the juice. Garnish each glass with a sprig of fresh mint and serve.

LIMITED ONE YEAR WARRANTY

Warranty: This product is warranted by Salton, Inc. to be free from defects in materials or workmanship for a period of (1) year from the original purchase date. This product warranty covers only the original consumer purchaser of the product.

Warranty Coverage: This warranty is void if the product has been damaged by accident in shipment, unreasonable use, misuse, neglect, improper service, commercial use, repairs by unauthorized personnel, normal wear and tear, improper assembly, installation or maintenance abuse or other causes not arising out of defects in materials or workmanship. This warranty is effective only if the product is purchased and operated in the USA, and does not extend to any units which have been used in violation of written instructions furnished with the product or to units which have been altered or modified or to damage to products or parts thereof which have had the serial number removed, altered, defaced or rendered illegible.

Implied Warranties: ANY IMPLIED WARRANTIES WHICH THE PURCHASER MAY HAVE ARE LIMITED IN DURATION TO ONE (1) YEAR FROM THE DATE OF PURCHASE. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.

Warranty Performance: During the above one-year warranty period, a product with a defect will be either repaired or replaced with a reconditioned comparable model (at our option) when the product is returned to the Repair Center, or the purchase price refunded. The repaired or replacement product will be in warranty for the balance of the one-year warranty period and an additional one-month period. No charge will be made for such repair or replacement.

Service and Repair: Should the appliance malfunction, you should first call toll-free 1 (800) 233-9054 between the hours of 9:00 am and 5:00 pm Central Standard Time and ask for CONSUMER SERVICE stating that you are a consumer with a problem. Please refer to model number LM8 when you call.

In-Warranty Service (USA): For an appliance covered under the warranty period, no charge is made for service or postage. Call for return authorization (1 800 233-9054).

Out-of Warranty Service: A flat rate charge by model is made for out-of-warranty service. Include \$10.00 (U.S.) for return shipping and handling. We will notify you by mail of the amount of the charge for service and require you to pay in advance for the repair or replacement.

For Products Purchased in the USA, but Used in Canada: You may return the product insured, packaged with sufficient protection, and postage and insurance prepaid to the USA address listed below. Please note that all customs duty / brokerage fees, if any, must be paid by you and we will require you to pay the cost of customs duty / brokerage fees to us in advance of our performing any service.

Risk During Shipment: We cannot assume responsibility for loss or damage during incoming shipment. For your protection, carefully package the product for shipment and insure it with the carrier. Be sure to enclose the following items with your appliance: any accessories related to your problem, your full return address and daytime phone number, a note describing the problem you experienced, a copy of your sales receipt or other proof of purchase to determine warranty status. C.O.D. shipments cannot be accepted.

To return the appliance, ship to:

Attn: Repair Center
Salton, Inc.
708 South Missouri Street
Macon, MO 63552

To contact us, please write to, call, or email:

Salton, Inc.
P.O. Box 1526
Columbia, MO 65205-1526
1(800) 233-9054
Email: Salton@Saltonusa.com

Limitation of Remedies: No representative or person is authorized to assume for Salton, Inc. any other liability in connection with the sale of our products. There shall be no claims for defects or failure of performance or product failure under any theory of tort, contract or commercial law including, but not limited to negligence, gross negligence, strict liability, breach of warranty and breach of contract. Repair, replacement or refund shall be the sole remedy of the purchaser under this warranty, and **in no event shall Salton be liable for any incidental or consequential damages, losses or expenses.** Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

Legal Rights: This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

For more information on Salton products: Visit our website: <http://www.salton-maxim.com>

"© 2001 Salton, Inc.
All Rights Reserved"

P/N 60806
Printed in China