


READ AND SAVE THESE INSTRUCTIONS

Milk Frother

**USE AND CARE GUIDE FOR
MODEL MEMF1BKIT**



IMPORTANT SAFEGUARDS

When using this appliance, basic safety precautions should always be followed including the following:

- Read all instructions.
- To protect against risk of electrical shock, do not immerse the frother body in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Do not leave unit on when not in use.
- Do not mix old and new batteries.
- Avoid contacting moving parts.
- Do not operate the appliance after the appliance malfunctions or is dropped or damaged in any manner.
- The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock or injury.

SAVE THESE INSTRUCTIONS

**THIS PRODUCT IS FOR HOUSEHOLD USE ONLY.
THIS IS NOT A TOY.**

ADDITIONAL IMPORTANT SAFEGUARDS

1. All users of this appliance must read and understand this Use and Care Guide before operating or cleaning this appliance.
2. If this appliance begins to malfunction during use, immediately release the Power Button. Do not use or attempt to repair the malfunctioning appliance. Contact Consumer Service.
3. Do not use this appliance for other than its intended use.

Your product may vary slightly from illustration.

Parts Identification

Before using your Melitta® Milk Frother for the first time, you should become familiar with all of the parts. Read all instructions and cautions carefully.




FIGURE A

Before First Use of Milk Frother

Attach, if desired, a convenient wall bracket mount with the hardware included, see Figure B.

NOTE: Make sure that the proper sized holes are drilled into the wall for mounting the anchors and screws.




FIGURE B

Install Batteries for Operation

The Milk Frother requires two AA batteries for operation.

1. To open, hold the Body Cover and twist the Frother Body clockwise to unlock, see Figure C.
2. Place the batteries onto the shelf, see Figure D.
3. Replace the Body Cover by lining up the notches inside the tip cover with the cutouts in the base of the unit. Turn Frother Body counterclockwise to lock into position, see Figure D.

NOTE: Check the batteries regularly. If the Milk Frother is not going to be used for a long period of time, remove the batteries for storage to avoid battery corrosion.




FIGURE C




FIGURE D

To Froth Milk

1. Select a container that is suitable for the microwave. Add skim milk to the container filling a little less than half full.
2. Heat the milk in the microwave until steaming without allowing it to boil. If the milk boils, it will lose its ability to froth. Cold milk can also be used.
3. Place the Wire Frothing Whisk directly below the top surface of the milk.
4. Press the Power Button to begin frothing, see Figure E. Carefully move the Wire Frothing Whisk up and down in the warm or cold milk to create froth. After approximately 10 seconds, you will have enough froth for 1-2 cups of cappuccino.
5. Press the Power Button to turn unit off.
6. Spoon the froth onto the top of a cup of coffee and add warm milk if desired.
7. The remaining warm milk may be used again to create additional froth.
8. Clean and dry thoroughly after each use.




FIGURE E

To Clean Milk Frother

1. After use, clean the Wire Frothing Whisk in warm water. The Wire Frothing Whisk DOES NOT DETACH from the Frother Body. DO NOT IMMERSE THE FROTHER BODY IN ANY LIQUID.
2. Dry the Wire Frothing Whisk thoroughly. If moisture remains in the Wire Frothing Whisk when placed on the Wall Bracket Mount, it can drip down onto the counter or on the wall.
3. To clean the Frother Body, wipe with a damp cloth and dry thoroughly.
4. Return Milk Frother to the Wall Bracket Mount for storage, see Figure A.

To Fill Spice Dispenser

1. Remove lid from spice dispenser, see Figure F.
2. Fill dispenser with your favorite topping for cappuccino, i.e. cinnamon, cocoa, or nutmeg.
3. Securely replace lid to dispenser.




FIGURE F

Additional Uses

The Milk Frother may be used as a mini-mixer. For example, you can prepare salad dressings, packet sauce and mixed drinks, or use it to whisk in syrup.

IMPORTANT NOTICE

*If any parts are missing or defective,
DO NOT return this product.*

Please call our Customer Service Department for assistance.

800-233-9054 Monday - Friday 9:00 am - 5:00 pm CST

Thank You

LIMITED 90-DAY WARRANTY

Warranty: This Melitta® product is warranted by Salton, Inc. to be free from defects in materials or workmanship for a period of 90 days from the original purchase date. This product warranty covers only the original consumer purchaser of the product.

Warranty Coverage: This warranty is void if the product has been damaged by accident in shipment, unreasonable use, misuse, neglect, improper service, commercial use, repairs by unauthorized personnel, normal wear and tear, improper assembly, installation or maintenance abuse or other causes not arising out of defects in materials or workmanship. This warranty is effective only if the product is purchased and operated in the USA, and does not extend to any unit which has been used in violation of written instructions furnished with the product, or to units which have been altered or modified, or to damage to products or parts thereof which have had the serial number removed, altered, defaced or rendered illegible.

Implied Warranties: ANY IMPLIED WARRANTIES WHICH THE PURCHASER MAY HAVE ARE LIMITED IN DURATION TO NINETY (90) DAYS FROM THE DATE OF PURCHASE. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.

Warranty Performance: During the above ninety (90) day warranty period, a product with a defect will be either repaired or replaced with a reconditioned comparable model (at our option) when the product is returned to the Repair Center, or the purchase price refunded. The repaired or replacement product will be in warranty for the balance of the ninety (90) day warranty period and an additional one-month period. No charge will be made for such repair or replacement.

Service and Repair: Should the appliance malfunction, you should first call toll-free 1-800-233-9054 between the hours of 9:00 am and 5:00 pm Central Standard Time and ask for CONSUMER SERVICE stating that you are a consumer with a problem. Please refer to model number MEMF1BKIT when you call.

In-Warranty Service (USA): For an appliance covered under the warranty period, no charge is made for service or postage. Call for return authorization 1-800-233-9054.

Out-of-Warranty Service: A flat rate charge by model is made for out-of-warranty service. Include \$8.00 (U.S.) for return shipping and handling. We will notify you by mail of the amount of the charge for service and require you to pay in advance for the repair or replacement.

For products Purchased in the USA, but used in Canada: You may return the product insured, packaged with sufficient protection, and postage and insurance prepaid to the USA address listed below. Please note that all customs duty / brokerage fees, if any, must be paid by you and we will require you to pay the cost of customs duty / brokerage fees to us in advance of our performing any service.

Risk During Shipment: We cannot assume responsibility for loss or damage during incoming shipment. For your protection, carefully package the product for shipment and insure it with the carrier. Be sure to enclose the following items with your appliance: any accessories related to your problem, your full return address and daytime phone number, a note describing the problem you experienced, a copy of your sales receipt or other proof of purchase to determine warranty status. C.O.D. shipments cannot be accepted.

To return the appliance, ship to: To contact us, please write to, call or email:

Attn: Repair Center
Salton, Inc.
708 South Missouri Street
Macon, MO 63552

Salton, Inc.
P.O. Box 6916
Columbia, MO 65205-6916
1-800-233-9054
Email: Salton@Saltonusa.com

Limitation of Remedies: No representative or person is authorized to assume for Salton, Inc. any other liability in connection with the sale of our products. There shall be no claims for defects or failure of performance or product failure under any theory of tort, contract or commercial law including, but not limited to negligence, gross negligence, strict liability, breach of warranty and breach of contract. Repair, replacement or refund shall be the sole remedy of the purchaser under this warranty, and in no event shall Salton, Inc. be liable for any incidental or consequential damages, losses or expenses. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

Legal Rights: This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

For more information on Salton products:

Visit our website: www.eSalton.com