

Find Timex manuals on following link.

<http://waterheatertimer.org/Woods-timers-and-manuals.html#Timex>

Easy-to-Set 7-day Electronic Lamp Timer

el TX12677T

What this lamp timer does:

This lamp timer is used to turn a lamp on and off automatically on a weekly cycle. The timer offers both random and programmable switching times.

How to use the lamp timer:

- Plug the lamp timer into the wall and wait 30 minutes while the internal battery charges. (This will allow the timer to be programmed and keep time, even when it is not plugged in. The timer must be plugged into the wall outlet to operate a lamp).
- Before using the lamp timer, make sure that the lamp works by plugging it into the wall outlet.
- While the lamp is on, unplug it from the wall.
- Set the timer to the current time and program it to turn your lamp on and off using the instructions below.
- Plug the lamp into the timer and plug the timer into the wall.
- Your lamp timer will turn your lamp on and off automatically, as programmed.

Setting Instructions:

To reset the timer:

Press MODE and PROG together to reset the clock and erase all programs.

To set the clock to current day and time:

- Press and hold the TIME button until the day icon flashes. Use the + or - buttons to select the current day.
- Press and hold the TIME button until the hour digit flashes. Use the + or - buttons to select the current hour. Note AM or PM.
- Press and hold the TIME button until the minute digits flash. Use the + or - buttons to select the current minute.
- Press and hold time until the minute digits no longer flash. The timer will return to clock mode and display current time all the time.

READ THIS BEFORE SETTING PROGRAMS

Press and hold the PROG button until the cursor begins flashing at the 12 o'clock position. Then, by pressing the PROG button, cycle through the days of the week and groups of days. Note that ON/OFF times can be programmed for days and/or groups of days.

Each day separately: MO, TU, WE, TH, FR, SA, SU

Groups of days:

MO TU WE TH FR – (program is the same every day for Monday through Friday)

SA SU – (program is the same for Saturday and Sunday)

MO TU WE TH FR SA SU – (program is the same for every day)

To Program:

1. Press and hold the PROG button until the cursor begins flashing at the 12 o'clock position.
2. Press PROG to advance to the day or day group you wish to program. (Example: SA SU).
3. Press + to advance the flashing cursor to the desired "on" time. (Example: 7:30PM).

4. Press MODE until the display reads "ON".
5. Using + button, move the cursor to select the period for the lamp to be ON. This period of "on time" will be high lighted at edge of the display. (Example: 7:30PM to 10:00PM). Note that the clock display will show the time day corresponding to the position of the flashing cursor.
6. Press MODE until "OFF" is displayed. Then advance the cursor through those periods the lamp should be off. (Example: 1:00AM to 6:30AM).
7. Pressing MODE and using the + or - buttons in this manner, will allow you to select between ON and OFF period.
8. Press TIME to exit the programming mode and return to the clock mode or
9. Press PROG and follow the instructions above to program the next day or group of days.

To Change a Program

Programs are changed by re-programming the timer.

- Press and hold PROG to enter programming mode.
- Press PROG to select the desired day or day group.
- Advance the cursor around the edge of the display using + or - and select between "ON" and "OFF" periods using the MODE button.

Viewing Programs

To view each day's program:

- Press and hold TIME.
- Use the + or - buttons to view all "on" and "off" periods for any day of the week.
- Wait 15 seconds and the timer will automatically return to clock mode. Important: Do not press the TIME button again during this 15 seconds as this causes the timer to enter clock setting mode.

To Override the Program

During normal use, there may be periods when the programmed on and off times are not desired. The override function can be used here.

When the timer is in clock mode, press MODE to select ON, OFF or AUTO.

When ON is selected, the lamp will remain on and program will not run.

When OFF is selected, the lamp will remain off and program will not run.

When AUTO is selected, the lamp will be turned on and off by the timer, as programmed.

Random Mode

The random mode turns a lamp on and off within 0 to 30 minutes of the programmed on/off times.

This security feature could foil would-be burglars trying to determine a set activity pattern in your home, as would be the case if the lamps turned on and off at the same time every day. It is particularly useful during vacations and other times when the house is vacant.

Press TIME and PROG together to set the timer to Random Mode.