


OWNER'S MANUAL
MODEL No. JW-1

Jewelry SpaTM

HOME JEWELRY CARE



saltonTM

Get a taste of the good life with Salton.

IMPORTANT SAFEGUARDS

Read all instructions before using

- 1 Always unplug your Salton Jewelry Spa™ immediately after using, while the activator switch is in the off position.
- 2 Always fill your Jewelry Spa™ with liquid while it is unplugged. Make sure the Jewelry Spa™ is unplugged prior to emptying liquids.
- 3 Do not place or store appliance where it can fall into a tub or sink.
- 4 Do not place in or drop into water or other liquid.
- 5 Do not reach for an appliance that has fallen into water. Unplug immediately


Warning: To reduce the risk of burns, electrocution, fire or injury to persons:

- 1 An appliance should never be left unattended when plugged in.
- 2 Close supervision is necessary when this appliance is used by, on, or near children or invalids.
- 3 Use this appliance only for its' intended use as described in the manual. Do not use attachments not recommended by Salton Housewares.
- 4 Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water. Return the appliance to a service center for examination and repair.
- 5 Keep the cord away from heated surfaces.
- 6 Do not let cord hang over edge of table, counter or touch hot surfaces.
- 7 Do not use flammable or toxic liquids.
- 8 Never drop or insert any object into any electrical opening.
- 9 Keep out of the reach of children.

SAVE THESE INSTRUCTIONS

How to Use Your Salton Jewelry Spa™

1. Fill Spa chamber (c) to the water line with clean, warm water. Add 1/2 teaspoon of mild **liquid** dishsoap.
2. Put jewelry to be cleaned in baskets, (b) taking care not to overload basket.
3. Place baskets into chamber with handle grips turned into the center portion of the Spa. Place lid (a) onto the Jewelry Spa,™ and plug into a 120 volt outlet.
4. Move activator switch (d) into the marked "High" position. After five to six minutes, move the switch back to "Off".
5. Unplug the Jewelry Spa,™ remove lid, jewelry baskets and empty liquid from Spa chamber. Refill with fresh, clean water.
6. Replace trays, lid and plug into 120 volt outlet.
7. Move activator switch into "Low" position for one minute of sonic treatment.
8. Switch to Off, remove lid and hang trays on Spa side rim, for drying.
9. Remove jewelry and place on soft, lint free cloth.
10. Unplug the Jewelry Spa™ and pour out liquid.
11. For best results always use fresh water.



A. View-through Lid
B. Vented Jewelry Baskets

C. Spa Chamber
D. ON/OFF Switch

LIMITED WARRANTY

Machines distributed by Salton Housewares, Inc. are warranted for one year from date of purchase against defects in workmanship and material. During that period these defects will be repaired or the product will be replaced at Salton's option, without charge. This warranty covers normal consumer usage and does not cover damage which occurs in shipment or failure which results from alteration, accident, misuse, abuse, neglect, installation, commercial use or improper maintenance. This warranty is effective only if the product is purchased and operated in the USA, and does not extend to any units which have been used in violation of written instructions furnished by Salton Housewares, Inc., or to units which have been altered or modified without authorization of Salton Housewares, Inc., or to damage to products or parts thereof which have had the serial number removed, altered, defaced or rendered illegible.

Service and Repair

DO NOT attempt to repair your SALTON JW-1 Jewelry Spa.™ Should the appliance malfunction, you should first call toll free 1-800-233-9054 between the hours of 9:00 am and 5:00 pm Central Standard Time and ask for CONSUMER CUSTOMER SERVICE stating that you are a consumer with a problem. If the problem cannot be resolved, you will be asked to return the machine to the factory for repair. Under no circumstances should you attempt to open the housing and repair the machine. Should you do this, your warranty will be voided.

To Return for Service

1. Securely package and return the product, PREPAID to: Salton Housewares, Inc., Repair Department, 550 Business Center Drive, Mt. Prospect, IL 60056
 2. Be sure to enclose:
 - a. Your name, address and phone number.
 - b. The date of purchase (or receipt as a gift).
 - c. An explanation of the malfunction or reason for return.
 - d. Six dollars (\$6.00) Check or Money Order payable to Salton Housewares, Inc. for return postage and handling.
 - e. To insure prompt "In-Warranty" service, be sure to include proof of date of purchase.
- We recommend you take the necessary precaution of insuring the parcel.
3. **Toll Free Number** 1-800-233-9054.

salton™