

OWNER'S MANUAL

Model No. T02

Electronic **2-Slice Toaster**

salton®

Get a taste of the good life with Salton.

Important Safeguards


When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

READ ALL INSTRUCTIONS BEFORE USING.

1. Do not touch hot surfaces. Use handles or knobs.
2. To protect against electrical hazards, do not immerse cord, plug, or the appliance in water or other liquid.
3. Close supervision is necessary when any appliance is used by or near children.
4. Unplug from outlet when not in use, and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning.
5. Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions, or has been dropped or damaged in any manner. Return appliance to Salton/Maxim Housewares, Inc. for examination, repair or electrical or mechanical adjustment.
6. The use of attachments not recommended by Salton/Maxim Housewares, Inc. may cause hazards.
7. Keep the cord away from heated surfaces. Do not let the cord hang over the edge of table or counter, as it could be pulled off.
8. Do not use outdoors.
9. Do not place on or near a hot gas or electric burner or in a heated oven.
10. Do not use the appliance for other than its intended use.
11. Oversized foods, metal foil packages or utensils must not be inserted in this appliance, as they may create a fire or electrical hazard.
12. A fire may occur if this toaster is covered or touching flammable material, including curtains, draperies, walls, etc., when in operation.
13. Do not attempt to dislodge food when toaster is plugged in.
14. Toasting lever must be in the "up" position before attaching or disconnecting the plug from wall outlet.

Save These Instructions

Getting to Know Your Electronic 2-Slice Toaster



1. Heat-resistant end panels
2. Recessed operating handle
NOTE: Toaster must be plugged in for handle to operate
3. Microchip browning selector
4. Crumb tray
5. Wipe-clean finish

Polarized Plug

This appliance has a polarized plug (one blade is wider than the other): To reduce the risk of electric shock, this plug is intended to fit into a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to modify the plug in any way.

Care and Maintenance

This appliance is for HOUSEHOLD USE ONLY. It may be plugged into any AC electrical outlet (ordinary household current). Do not use any other type of outlet.

IMPORTANT: Before using, operate the toaster without bread in order to burn off residues on the heating elements. When doing this, we suggest that you set the microchip browning selector at a medium setting.

Short Cord Instructions

A short power-supply cord is provided to reduce the risk resulting from becoming entangled in or tripping over a longer cord.

Longer detachable power-supply cords or extension cords are available and may be used if care is exercised in their use.

If a longer detachable power-supply cord or extension cord is used, (1) the marked electrical rating of the extension cord should be at least as great as the electrical rating of the appliance, and (2) the longer cord should be arranged so that it will not drape over the counter top or table top where it can be pulled on by children or tripped over unintentionally.

How To Use Your New Electronic Toaster

Adjust the microchip browning selector to the desired setting. Exact settings are difficult to recommend due to personal preference; experiment to suit individual taste. Thick foods and those containing fillings will require a longer toasting time. Turn selector to a medium or high setting to increase time. Some frozen pastries and toaster foods may require two heating cycles for proper results.

Remove all protective wrappings from food before placing in toasting wells. (Avoid toasting torn slices of bread and broken pastries, which may get lodged in toasting wells.) Place bread or toaster food into toasting wells and depress the handle.

When toast or toaster food is ready, it will pop up automatically, and the toaster will switch off.

NOTE: Do not make adjustments to the microchip browning selector while the toaster is in use. To interrupt the cycle, gently lift the handle.

When toasting a single slice, the bread or toaster food may be placed in either toasting well but may toast slightly darker on the inside than on the outside.

To Clean

Always unplug the toaster and allow to cool fully before cleaning.

Crumb Tray

Open the crumb tray by grasping the knob on the base and sliding the tray toward the cord while lifting. Brush crumbs from the tray and, if necessary, wipe with a clean, damp cloth. Always dry the tray thoroughly before closing it. When closing the tray, be sure that the latch catches on the slot.

Exterior

Wipe surface with a clean, damp cloth. Do not use abrasive cleaners, as they may scratch the surface.

NOTE: Never immerse the toaster in water. Never use a metal instrument to dislodge crumbs.

IMPORTANT NOTICE

If any parts are missing or defective,

DO NOT return this product.

Please call our Customer Service Department for assistance.

800-233-9054 Monday - Friday 9am - 5pm CST

Thank You

ONE-YEAR LIMITED WARRANTY

This Salton/MAXIM product warranty extends to the original consumer purchaser of the product.

Warranty Duration: This product is warranted to the original consumer purchaser for a period of one (1) year from the original purchase date.

Warranty Coverage: This product is warranted against defective materials or workmanship. This warranty is void if the product has been damaged by accident, in shipment, unreasonable use, misuse, neglect, improper service, commercial use, repairs by unauthorized personnel or other causes not arising out of defects in materials or workmanship. This warranty is effective only if the product is purchased and operated in the USA, and does not extend to any units which have been used in violation of written instructions furnished by Salton/MAXIM Housewares, Inc., or to units which have been altered or modified or to damage to products or parts thereof which have had the serial number removed, altered, defaced or rendered illegible.

Warranty Disclaimers: This warranty is in lieu of all warranties expressed or implied and no representative or person is authorized to assume for Salton/MAXIM Housewares, Inc. any other liability in connection with the sale of our products. There shall be no claims for defects or failure of performance or product failure under any theory of tort, contract or commercial law including, but not limited to, negligence, gross negligence, strict liability, breach of warranty and breach of contract.

Warranty Performance: During the above one-year warranty period, a product with a defect will be either repaired or replaced with a reconditioned comparable model (at Salton/MAXIM's option) when the product is returned to the Salton/MAXIM facility. The repaired or replacement product will be in warranty for the balance of the one-year warranty period and an additional one-month period. No charge will be made for such repair or replacement.

Service and Repair

Should the appliance malfunction, you should first call toll-free 1-800-233-9054 between the hours of 9:00 am and 5:00 pm Central Standard Time and ask for CUSTOMER SERVICE stating that you are a consumer with a problem.

In-Warranty Service: For an appliance covered under the warranty period, no charge is made for service or postage. Call for pre-paid return mailing label. (U.S. Customers Only)

Out-of Warranty Service: A flat rate charge by model is made for out-of-warranty service. Include \$6.00 for return shipping and handling.

Salton/MAXIM cannot assume responsibility for loss or damage during incoming shipment. For your protection, carefully package the product for shipment and insure it with the carrier. Be sure to enclose the following items with your appliance: any accessories related to your problem; your full return address and daytime phone number; a note describing the problem you experienced; a copy of your sales receipt or other proof of purchase to determine warranty status. C.O.D. shipments cannot be accepted.

Return the appliance to:

ATTN: Repair Department, Salton/Maxim Housewares, Inc.
550 Business Center Drive, Mt. Prospect, Illinois 60056

For more information on Salton/MAXIM products:

visit our website: <http://www.SALTON-MAXIM.com> or

E-mail us at SALTON 550 @ aol.com