


# cook's essentials®

HIGH PERFORMANCE KITCHENWARE



## THERMAL COFFEEMAKER

MODEL CETCM10P

OWNER'S MANUAL

# IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed, including the following:

1. Read all instructions.
2. Do not touch hot surfaces. Use handles or knobs.
3. To protect against electric shock do not place cord, plugs or appliance in water or other liquid.
4. Close supervision is necessary when any appliance is used by or near children.
5. Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
6. Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner. Contact Consumer Service for examination, repair or adjustment.
7. The use of an accessory not evaluated for use with this appliance may cause injuries.
8. Do not use outdoors.
9. Do not let cord hang over edge of table or counter, or touch hot surfaces.
10. Do not place on or near a hot gas or electric burner, or in a heated oven.
11. To disconnect, turn any control to the "off", then remove plug from wall outlet.
12. Do not use appliance for other than intended use.
13. Be certain Lids are securely in place before operating appliance.
14. Scalding may occur if the lid is removed during the brewing cycles.

## SAVE THESE INSTRUCTIONS

**For Household Use Only**

# Additional Important Safeguards

***WARNING: This appliance generates heat and escaping steam during use. Use proper precautions to prevent the risk of burns, fires, or other injury to persons or damage to property.***

1. All users of this appliance must read and understand this Owner's Manual before operating or cleaning this appliance.
2. The cord to this appliance should be plugged into a 120V AC electrical outlet only.
3. Use **water only** in this appliance! Do not put any other liquids or food products in this appliance. Do not mix or add anything to the water placed in this appliance, except as instructed in the User Maintenance Instructions to clean the appliance.
4. DO NOT attempt to move an appliance containing hot liquids. Allow appliance to cool completely before moving.
5. Keep appliance at least 4 inches away from walls or other objects during operation. Do not place any objects on top of appliance while it is operating. Place the appliance on a surface that is resistant to heat.
6. If this appliance begins to malfunction during use, immediately unplug the cord. Do not use or attempt to repair the malfunctioning appliance.
7. If this appliance falls or accidentally becomes immersed in water or any other liquid, unplug it immediately. **Do not reach into the water! Do not use this appliance after it has fallen into or has become immersed in water.** Contact Consumer Service for examination and repair.
8. Do not leave this appliance unattended during use.
9. The appliance must be left to cool down sufficiently before adding more water to avoid splattering.
10. Always use fresh, cool water in your appliance. Warm water or other liquids, except as listed in cleaning section, may cause damage to the appliance.
11. DO NOT put Carafe into a microwave.
12. DO NOT lift Filter Basket Lid until brewing is complete, and all parts have cooled.
13. The carafe is designed for use with this appliance. It must never be used on a range top.
14. Do not use a damaged carafe or a carafe having a loose or weakened handle.
15. ***CAUTION: To prevent injury when utilizing Pause and Pour (drip-stop) feature, replace Carafe within 20 seconds of removing during brewing process.***

## Polarized Plug

This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit into a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to modify the plug in any way.

## Short Cord Instructions

A short power-supply cord is provided to reduce the risk resulting from becoming entangled in or tripping over a longer cord. Longer detachable power-supply cords or extension cords are available and may be used if care is exercised in their use.

If a longer detachable power-supply cord or extension cord is used, (1) the marked electrical rating of the extension cord should be at least as great as the electrical rating of the appliance, and (2) the cord should be arranged so that it will not drape over the counter top or table top where it can be pulled on by children or tripped over unintentionally.

## Electric Power


If the electric circuit is overloaded with other appliances, your appliance may not operate. It should be operated on a separate electrical circuit from other appliances.

**CAUTION:** To prevent Plasticizers to migrate from the finish of the counter top or table top or other furniture, place **NON-PLASTIC** coasters or placemats between the appliance and the finish of the counter top or table top.

**Failure to do so may cause the finish to darken, permanent blemishes may occur or stains can appear.**

***WARNING: TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT REMOVE THE BOTTOM COVER. NO USER SERVICEABLE PARTS INSIDE. REPAIR SHOULD BE DONE BY AUTHORIZED SERVICE PERSONNEL ONLY.***

# Getting to Know Your cook's essentials® CETCM10P Coffeemaker



- |   |  |
|---|--|
| 1. Base Plate                           | 10. Removable Filter Basket<br>(P/N 30976) |
| 2. Carafe (P/N 30973)                   | 11. Time Select Button (HOUR)              |
| 3. Carafe Lid (P/N 30974)               | 12. Time Select Button (MIN)               |
| 4. Control Panel                        | 13. AUTO Light (Red)                       |
| 5. Water Level Indicator                | 14. Digital Display                        |
| 6. Filter Lid Release Button            | 15. ON Light (Green)                       |
| 7. Hinged Filter Lid                    | 16. Power Select Button                    |
| 8. Water Reservoir Cover<br>(P/N 30977) | 17. CLOCK/TIMER Button                     |
| 9. Water Reservoir                      |  |

## Before First Use

**WARNING!** *To reduce risk of fire or electric shock, do not immerse Cord, Plug or appliance in water or any other liquid.*

1. Before preparing coffee in your new coffeemaker, thoroughly clean the Carafe, Carafe Lid and Removable Filter Basket in warm, soapy water. Rinse and dry. Replace disassembled parts. **Note:** The Removable Filter Basket must be placed into the coffeemaker with the arrow pointing toward the back of the unit.
2. Clean the inside of the coffeemaker by brewing two full carafes of tap water (see *Brewing Instructions*). Do not place a filter or coffee in the Removable Filter Holder for this initial cleaning.

**Note:** At the end of the first brewing cycle, turn the coffeemaker off and wait ten minutes for the appliance to cool. Turn unit on and brew second carafe of cool water.

## Coffee Filters

Cone-shaped paper filters are available locally at grocery stores and where coffeemakers are sold. Standard #4 filters should be used. Permanent gold filters may also be purchased, eliminating the need for disposable papers filters.

The use of basket-style paper filters is not recommended, since they do not conform to the shape of the filter basket and may cause coffee to back up and spill over during brewing.

# Brewing Instructions

1. Place the Thermal Coffeemaker on a flat, level surface. Plug the unit into a 120V, AC electrical outlet.
2. Press the Filter Lid Release Button to open the Filter Lid.
3. Place a #4 cone-shaped paper filter into the Removable Filter Basket. Measure one level tablespoon of drip or regular grind coffee for each cup of coffee desired. For stronger or milder coffee, adjust amount of coffee to suit your taste. **Note:** We recommend using coffee ground specifically for automatic drip coffeemakers.
4. Close the Filter Lid.
5. Raise the Water Reservoir Lid. Fill the Thermal Carafe with cold water and pour it into the Water Reservoir to the desired level. No less than two cups are recommended.

**Important:** Always use fresh, cool water in your appliance. Warm water or other liquids, except as listed in cleaning section, may cause damage to the appliance.

**Note:** The amount of brewed coffee will always be less than the amount of water placed into the coffeemaker, since about 10% is absorbed by the coffee grounds and filter.

6. For optimal thermal retention, preheat the Thermal Carafe by rinsing it with hot water. Place the Lid on the Carafe and turn clockwise until the arrows are aligned. Coffee will not flow in correctly if misaligned. Place the Carafe on the Base Plate.
7. In order to turn unit on, press the Power Select Button twice. (By pressing once the timer can be set - please refer to page 9.) The green "ON" light will illuminate, indicating that the brewing cycle has begun. Hot water will be dispensed gently and evenly through the coffee grounds. When all the water has been pumped out of the Water Reservoir the coffeemaker will switch off automatically.
- Note:** If you prefer to use the Timer to preset the coffeemaker, see the *Using the Timer* section.
8. To pour a cup of coffee before the brew cycle is complete, simply remove the Thermal Carafe from the Base Plate and pour. Brewing will continue but dripping will automatically pause. Return the Thermal Carafe to the Base Plate within 20 seconds; dripping will resume.

**CAUTION:** To prevent injury when utilizing Pause and Pour (drip-stop) feature, replace Carafe within 20 seconds of removing during brewing process.

9. Upon completion of the brew cycle, wait until dripping has stopped before removing the Carafe. The Carafe Lid should be kept in place to facilitate safe serving and help keep coffee at proper serving temperature.

## Brewing Instructions (Cont.)

You may wish to remove the Thermal carafe to a more convenient location. If so, seal the Thermal Carafe by turning the Carafe Lid clockwise until tight. The Thermal Carafe will maintain the serving temperature for several hours.

10. Switch coffeemaker to off since unit is not in use.
11. To brew another Carafe of coffee, turn unit off and wait 10 minutes to allow heating element to cool. **Important:** If unit is not allowed to cool before immediate repeated use, water placed in water chamber may become overheated and a spray of steam could be released from opening, creating a risk of burns.
12. When not in use unplug the Base Assembly from the wall outlet. Allow the unit to cool completely before cleaning. See *User Maintenance Instructions*.

## Brewing A Second Pot Of Coffee

As mentioned above, it is recommended that the coffeemaker should be in the Off position for 10 minutes between cycles, in order to allow unit to cool. While unit is in the Off position, dispose of used coffee filter, rinse Carafe and the Removable Filter Holder in water. Place a fresh filter in basket. Repeat brewing procedure.



# Using the Timer Control

Your coffeemaker has a built in multifunction timer. The following sections describe the proper use of the timer.

## Setting The Clock

To set the clock, simply press and hold the "CLOCK/TIMER" Button and press the "HOUR" Button until the desired hour has been reached. Make sure the proper "AM/PM" indicator is shown on the left side of the Digital Display. Press the "MIN" Button until the desired minutes have been reached.

**Note:** Unplugging the unit will reset the clock to 12:00.

## Presetting The Brewing Cycle

To preset your coffeemaker to begin brewing at a later time, first follow steps 1-3 in the *Brewing Instructions* Section. Check to make sure that the clock is set to the correct time. If it is not, follow the above instructions to set the clock. Press the "CLOCK/TIMER" Button once, the Digital Display will show "AUTO BREW". Press the "HOUR" and "MIN" Buttons until the desired brew time is reached. Make sure the proper AM/PM appears on the left side of the Digital Display. Press the Power Select Button once. The red "AUTO" light will illuminate, indicating that the coffeemaker is now waiting for the preset brew time to be reached before it begins the brewing cycle.

## Auto Shut-Off

As an added convenience, your coffeemaker has been designed with an auto shut-off feature. When the brewing cycle is complete, the coffeemaker will automatically shut-off.

## Hints for great tasting coffee

- A clean coffeemaker is essential for making great tasting coffee. Regular cleaning, as specified in *User Maintenance Instructions* is highly recommended. Always use fresh, cool water in your coffeemaker. Finer grinds, such as drip and ADC coffee, promote fuller extraction and provide rich, full-bodied coffee. Regular grind will require slightly more coffee per cup to provide the strength of a finer grind.
- Store coffee in a cool, dry place. Once coffee has been opened, keep it tightly sealed in the refrigerator to maintain freshness. For optimum coffee, buy whole beans and grind them just before brewing.
- Do not re-use coffee grounds since this will greatly impair coffee flavor.
- Reheating coffee is not recommended. Coffee is at its peak flavor immediately after brewing.
- Small oil droplets on the surface of brewed, black coffee is due to the extraction of oil from the coffee grounds. Oiliness may occur more frequently if heavily roasted coffees are used. Over extraction may also cause oiliness, indicating a need to clean your coffeemaker.

# User Maintenance Instructions

This appliance requires little maintenance. It contains no user-serviceable parts. Any servicing requiring disassembly other than cleaning must be performed by a qualified appliance repair technician.

**WARNING:** *Unplug from wall outlet before cleaning.*

## Care And Cleaning Instructions

1. Always make sure coffeemaker is unplugged and Base Plate is cool before attempting to clean.
2. After daily use, the Removable Filter Basket, Thermal Carafe and Carafe Lid should be washed in warm, soapy water.
3. If necessary, wipe the outside of the coffeemaker with a soft, damp cloth and wipe dry. Do not use abrasive cleansers, scouring pads or steel wool.

Special cleaning of your coffeemaker is recommended at least once a month, depending on frequency of use and quality of water used in the unit. If water in your area is especially hard, the following cleaning procedure should be performed every two weeks, since minerals in water can detract from the flavor of the coffee and possibly lengthen brew time.

1. Fill the Carafe with one part white vinegar to three parts cold water. Pour water and vinegar solution into the water chamber.
2. Open the Hinged Filter Lid, place a paper filter in the Removable Filter Holder then close the Lid. Place Carafe on Base Plate. Press the Power Select Button to ON. **Note:** During cleaning, more steam will occur than during normal brewing.
3. KEEP THE COFFEEMAKER ON UNTIL HALF THE WATER HAS CYCLED THROUGH THE COFFEEMAKER, AS CAN BE VIEWED THROUGH THE WATER LEVEL INDICATOR. Press the Power Select Button to OFF. When liquid stops dripping from the Filter Basket into the Carafe, remove the carafe and allow the liquid to cool for 10 minutes. When cooled, pour liquid back into the water chamber.
4. Return carafe to Base Plate.
5. Switch control to ON. Repeat procedure, allowing all the cleaning solution to empty into the Carafe. After dripping has stopped, discard contents of carafe.
6. After allowing the coffeemaker to cool for 10 minutes, rinse it out by brewing a carafe full of cold water. Make sure to insert a fresh filter into the Removable Filter Basket before brewing.
7. At the end of the brew cycle, press the Power Select Button to OFF. Discard water in the carafe. Remove used filter and wash the Carafe and Removable Filter Basket in warm, soapy water. Rinse and Dry.
8. When coffeemaker has cooled, wipe exterior with a dry cloth.

