

**OWNER'S MANUAL**  
Model No. SL1

**FAST, HANDS-FREE OPERATION**  
**SALAD SPINNER**



**salton®**

*Get a taste of the good life with Salton.*

# Important Notes About Your Salton® Salad Spinner

Your Salton® Salad Spinner needs no special care other than cleaning. If servicing becomes necessary, please refer to the Warranty section of this booklet. Do not attempt to repair it yourself.

**DO NOT IMMERSE MOTOR BASE IN WATER OR OTHER LIQUID.**


## **BATTERIES:**

Four "C" cells (not included) are inserted in receptacles at the bottom of the Salad Spinner. Alkaline or heavy duty batteries are recommended for long service.

## How to Use

Your Salad Spinner uses centrifugal force to remove excess water from salad greens after rinsing.

1. Place Motor Base on a dry, level surface. Secure Outer Bowl into Base by aligning feet of Outer Bowl into recesses of Base. Outer bowl will drop into place. The Outer Bowl must always be secured into Base before operation.
2. Remove core from lettuce and separate leaves.
3. Place salad greens in Slotted Basket, filling basket no more than 2/3 full. Do not overfill slotted basket with greens as this can interfere with the spinning action and cause Cover to lift. Extra vegetables, such as green onions, fresh mush-



rooms or cherry tomatoes can be added for rinsing and spinning with the salad greens. They should be placed at the bottom of the Slotted Basket, making sure their weight is evenly distributed to prevent vibration during spinning.

4. Thoroughly rinse greens directly in Slotted Basket under cold tap water.
5. After rinsing, distribute salad greens loosely in Slotted Basket, making sure the weight is evenly distributed for best spinning results. If the weight is not evenly distributed, vibration or rocking may occur during operation.
6. Place Slotted Basket inside the Outer Bowl. Rotate the Slotted Basket slightly until it is locked in place over the Driver. Place Cover onto Bowl. Never operate Spinner without Cover securely in place. Turn switch to "ON" position and allow salad greens to spin for 20 to 30 seconds. You may secure Spinner by placing your hand on the Cover during operation. Turn switch "OFF" and remove Cover. If additional spinning is necessary, redistribute salad greens inside Slotted Basket, cover and switch to "ON" for several seconds, then switch back to "OFF."
7. Remove Cover and lift Slotted Basket out of Outer Bowl. Then remove Outer Bowl from Base and drain off water. Prepare salad as desired. If you wish to crisp salad greens before making salad, return Slotted Basket to Outer Bowl, cover and refrigerate.

**DO NOT PLACE MOTOR BASE IN REFRIGERATOR.**

## Care and Cleaning

1. Wash Slotted Basket, Bowl and Cover in hot, soapy water with a dishcloth or sponge, rinse and dry. Do not use any abrasive scouring pads or powders on these parts as scratching will occur. The Slotted Basket, Bowl and Cover can be washed in an automatic dishwasher, TOP RACK ONLY. To prevent scratching, position these pieces into the rack so they do not touch one another or other objects being cleaned.
2. Wipe Motor Base if necessary with a damp cloth and dry. Do not use any abrasive scouring pads or powders on Base as scratching will occur.

**DO NOT IMMERSE MOTOR BASE IN WATER OR OTHER LIQUID.**

# ONE-YEAR LIMITED WARRANTY

This Salton/MAXIM product warranty extends to the original consumer purchaser of the product.

**Warranty Duration:** This product is warranted to the original consumer purchaser for a period of one (1) year from the original purchase date.

**Warranty Coverage:** This product is warranted against defective materials or workmanship. This warranty is void if the product has been damaged by accident, in shipment, unreasonable use, misuse, neglect, improper service, commercial use, repairs by unauthorized personnel or other causes not arising out of defects in materials or workmanship. This warranty is effective only if the product is purchased and operated in the USA, and does not extend to any units which have been used in violation of written instructions furnished by Salton/MAXIM Housewares, Inc., or to units which have been altered or modified or to damage to products or parts thereof which have had the serial number removed, altered, defaced or rendered illegible.

**Warranty Disclaimers:** This warranty is in lieu of all warranties expressed or implied and no representative or person is authorized to assume for Salton/MAXIM Housewares, Inc. any other liability in connection with the sale of our products. There shall be no claims for defects or failure of performance or product failure under any theory of tort, contract or commercial law including, but not limited to, negligence, gross negligence, strict liability, breach of warranty and breach of contract.

**Warranty Performance:** During the above one-year warranty period, a product with a defect will be either repaired or replaced with a reconditioned comparable model (at Salton/MAXIM's option) when the product is returned to the Salton/MAXIM facility. The repaired or replacement product will be in warranty for the balance of the one-year warranty period and an additional one-month period. No charge will be made for such repair or replacement.

## Service and Repair

Should the appliance malfunction, you should first call toll-free 1-800-233-9054 between the hours of 9:00 am and 5:00 pm Central Standard Time and ask for CONSUMER CUSTOMER SERVICE stating that you are a consumer with a problem.

**In-Warranty Service:** For an appliance covered under the warranty period, no charge is made for service or postage. Call for pre-paid return mailing label. (U.S. Customers Only)

**Out-of Warranty Service:** A flat rate charge by model is made for out-of-warranty service. Include \$6.00 for return shipping and handling.

Salton/MAXIM cannot assume responsibility for loss or damage during incoming shipment. For your protection, carefully package the product for shipment and insure it with the carrier. Be sure to enclose the following items with your appliance: any accessories related to your problem; your full return address and daytime phone number; a note describing the problem you experienced; a copy of your sales receipt or other proof of purchase to determine warranty status. C.O.D. shipments cannot be accepted.

Return the appliance to:

ATTN: Repair Department  
Salton/Maxim Housewares, Inc.  
550 Business Center Drive  
Mt. Prospect, Illinois 60056