


OWNER'S MANUAL
Model No. MW-1

**Hot Spot™
Beverage Warmer**



Enjoy your favorite hot beverage at your leisure! The Hot Spot™ will keep it at just the right drinking temperature. Great for home and office!

salton™

IMPORTANT SAFEGUARDS

When using your Sallon Hot Spot™ Beverage Warmer or any electrical appliance, these basic safety precautions should be followed, including the following:

1. Read all instructions.
2. Do not touch hot surfaces. Handle by plastic sides only.
3. To protect against electrical hazard, do not immerse cord, plug or base unit in water or other liquid.
4. Close supervision is necessary when any appliance is used by or near children.
5. Unplug from outlet and allow to cool before cleaning.
6. Do not operate appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner. Return appliance to Sallon/Maxim Group for examination or repair.
7. The use of accessories or attachments not recommended by Sallon/Maxim Group may cause fire, electric shock, or injury.
8. Do not use outdoors; this product is for household use.
9. Do not let cord hang over edge of table or counter, or touch hot surfaces.
10. Do not place on or near a hot gas or electric burner, or in a heated oven.
11. Do not move appliance when supporting a container of hot liquids.
12. To disconnect, turn any control to "off", then remove the plug from wall outlet.
13. Do not use appliance for other than intended use.
14. To reduce the risk of injury, DO NOT drape cord over the counter top or tabletop where it can be pulled on by children or tripped over unintentionally.

SAVE THESE INSTRUCTIONS
HOUSEHOLD USE ONLY

INSTRUCTIONS FOR USE

The Salton Hot Spot™ Beverage Warmer is designed to keep a cup of hot coffee, soup, or other beverages at perfect drinking temperature. It is not intended to heat a cold cup of coffee, only to maintain a drinking temperature.

The Coffee Warmer has a switch to turn the unit on and off. Slide the switch to "OFF" position when not in use.

Use with your favorite cup...any china, glass or ceramic. Not intended for use with plastic or styrofoam cups.

CARE AND CLEANING

Salton's Hot Spot™ Beverage Warmer requires very little care and cleaning. Periodically, wipe the surface of the unit off (Be sure unit is cold and disconnected) with a damp cloth or sponge. To remove stubborn soil, use a mild non-abrasive cleaner.

LIMITED WARRANTY

Machines distributed by Salton/Maxim Group are warranted for one year from date of purchase against defects in workmanship and material. During that period these defects will be repaired or the product will be replaced at Salton's option, with out charge. This warranty covers normal consumer usage and does not cover damage which occurs in shipment or failure which results from alteration, accident, misuse, abuse, neglect, installation, commercial use or improper maintenance. This warranty is effective only if the product is purchased and operated in the USA, and does not extend to any units which have been used in violation of written instructions furnished by Salton/Maxim Group or to units which have been altered or modified without authorization of Salton/Maxim Group or to damage to products or parts thereof which have had the serial number removed, altered, defaced or rendered illegible.

Service and Repair


DO NOT attempt to repair your Salton Hot Spot™ Beverage Warmer. Should the machine malfunction, you should first call toll free (800) 233-9054 between the hours of 8:30 am and 5:00 pm Central Standard Time and ask for CONSUMER CUSTOMER SERVICE stating that you are a consumer with a problem. If the problem cannot be resolved you will be asked to return the machine to the factory for repair. Under no circumstances should you attempt to open the housing and repair the machine. Should you do this, your warranty will be voided.

To Return for Service

1. Securely package and return the product, PREPAID to - Salton/Maxim Group Repair Department, 550 Business Center Drive, MT. Prospect, IL 60056.
2. Be sure to enclose:
 - a. Your name, address and phone number.
 - b. The date of purchase (or receipt as a gift).
 - c. An explanation of the malfunction or reason for return.

To insure prompt "In-Warranty" service, be sure to include proof of date of purchase.

We recommend you take the necessary precaution of insuring the parcel.



salton™