
GEORGE FOREMAN™


DOUBLE CHAMPION OUTDOOR GRILL STAND



IMPORTANT: Use the Outdoor Grill Stand only with George Foreman Double Champion Indoor/Outdoor Grill, Model GGR62. Do not use this Outdoor Grill Stand for any other purpose!



Parts of the Grill Stand



- A. Center Stand
- B. Left Side Cart (w/o Wheels)
- C. Right Side Cart (w/ Wheels)
- D. Drip Tray Holder (P/N 21171)
- E. Center Stand Bolt (P/N 21172)

Hardware Pack (P/N 21173)

- F. 'C' Clamps (4)
- G. 1-3/4" Screws (4)
- H. Thick Washers (8)
- I. Wing Nuts (5)
- J. Thin Washers (3)


Assembly


NOTE: During shipping, the Center Stand Tray screws may become loose or fall out. Please check underside of each Tray to be sure small screws are in place and secure.

Always use Grill Stand on a dry, flat and stable surface.

Attach Left Side Cart to Center Stand


- Locate Center Stand (A). Lift up Center Stand Trays as shown. Be sure each Retainer is pushed all the way up and locked into place.
- Locate Left Side Cart (w/o Wheels) (B).
- 3. Place Left Side Cart (with legs facing away from Center Stand) to left of Center Stand as shown. Align holes in Left Side Cart front leg with holes in Center Stand frame.
- 4. Push a 1-3/4" screw (G) through hole in Left Side Cart Leg. Thread the screw through one thick washer (H). Then push screw through Center Stand Frame. Secure screw with wing nut (I) from opposite side.
- 5. Repeat for Left Side Cart back leg.






Attach Right Side Cart to Center Stand

- Locate Right Side Cart (w/ Wheels) (C).
- 2. Attach Right Side Cart to Center Stand by following steps 3-5 above (under "Attach Left Side Cart to Center Stand").



Attach Support Pegs to Retainer

- Lift up each Support Peg and push through holes on sides of Retainer (on Center Stand).
- 2. Attach each
 Support Peg to
 Retainer with a "C"
 Clamp (F) as shown.





Assemble Bottom Trays to Center Stand

- Lift each Bottom Tray toward center.
- Align center holes at front and back of Bottom Trays with long slot on Center Stand.
- Push a thin washer
 (J) over end of Center Stand Bolt
 (E).
- 4. Thread Center
 Stand Bolt through
 long slot on Center
 Stand and through
 aligned holes in
 Bottom Trays (front
 and back).
- 5. Once Bolt is threaded through to back long slot, place a thin washer (J) over bolt end and secure with wing nut.

Assemble Drip Tray Holder

- Position Drip Tray Holder (D) as shown so holes in Drip Tray Holder align with front legs.
- Push Drip Tray
 Holder down over
 front legs. Be sure
 Drip Tray Holder is
 seated securely.





Place Grill onto Grill Stand


IMPORTANT: This Grill Stand is intended to fit with the George Foreman "Double Champion Indoor/Outdoor Electric Grill" Model GGR62 only. Do not attempt to use Stand with any other type of Grill.

- Hold Model GGR62 Grill above Stand as shown.
- Lower Grill onto Stand so legs on Grill fit OVER stand legs.



Secure Grill to Grill Stand


- Locate Hooks on each side of Grill Stand (near front side of trays).
- 2. To secure Grill onto Stand, lift each Hook up and hook around small nub on side of Grill leg.



Place Drip Tray into Drip Tray Holder

 Place Drip Tray (sold with Grill) onto Drip Tray Holder (D) (and under Grill Handle).

NOTE: Always empty Drip Tray and remove from Stand when not in use.




Please refer to Model GGR62 Owner's Manual for important Safety Information, Operating Instructions, and Outdoor Grilling instructions.

Storage

Always remove Drip Tray before removing Indoor/Outdoor Grill and Drip Tray Holder from Stand. Store Outdoor Grill Stand when not in use. It is recommended to store the Grill indoors.

- To remove Grill from Stand, unlatch Hooks on each side and lift Grill straight up. Also, lift Drip Tray Holder and remove.
- 2. To fold up Stand, push in both Retainer Release Clamps simultaneously and gently pull up on Center Stand. As Stand begins to fold, push down on side trays.
- 3. Locate Hook on back
 Support Peg. Slide Hook
 up along Support Peg and
 rotate Hook onto opposite
 Support Peg. This will
 lock the Stand into the
 "closed" position.



ONE-YEAR LIMITED WARRANTY

This Salton, Inc. product warranty extends to the original consumer purchaser of the product.

Warranty Duration: This product is warranted to the original consumer purchaser for a period of one (1) year from the original purchase date.

Warranty Coverage: This product is warranted against defective materials or workmanship. This warranty is void if the product has been damaged by accident, in shipment, unreasonable use, misuse, neglect, improper service, commercial use, repairs by unauthorized personnel or other causes not arising out of defects in materials or workmanship. This warranty is effective only if the product is purchased and operated in the USA and Canada, and does not extend to any units which have been used in violation of written instructions furnished by Salton, Inc., or to units which have been altered or modified or to damage to products or parts thereof which have had the serial number removed, altered, defaced or rendered illegible.

Warranty Disclaimers: This warranty is in lieu of all warranties expressed or implied and no representative or person is authorized to assume for Salton, Inc. any other liability in connection with the sale of our products. There shall be no claims for defects or failure of performance or product failure under any theory of tort, contract or commercial law including, but not limited to, negligence, gross negligence, strict liability, breach of warranty and breach of contract.

Salton, Inc. is not responsible or liable for indirect, special or consequential damages arising out of or in connections with the use or performance of the product or other damages with respect to loss of property, or loss of revenues or profit.

Warranty Performance: During the above one-year warranty period, a product with a defect will be either repaired or replaced with a reconditioned comparable model (at Salton, Inc.'s option) when the product is returned to the Salton, Inc. facility. The repaired or replacement product will be in warranty for the balance of the one-year warranty period and an additional one-month period. No charge will be made for such repair or replacement.

Service and Repair

If service is required, you should first call toll-free 1-800-233-9054 between the hours of 8:00 am and 5:00 pm Central Standard Time and ask for CONSUMER SERVICE. Please refer to model GGR64 when you call.

In-Warranty Service (USA) for an appliance covered under the warranty period, no charge is made for service or postage. Contact Consumer Service for return authorization.

In-Warranty Service (Canada) for an appliance covered under the warranty period, no charge is made for service or postage. Please return the product insured, packaged with sufficient protection, and postage and insurance prepaid to the address listed below. Customs duty/brokerage fee, if any, must be paid by the consumer.

Out-of-Warranty Service: A flat rate charge by model is made for out-of-warranty service. Include \$10.00 (U.S.) for return shipping and handling.

Salton, Inc. cannot assume responsibility for loss or damage during incoming shipment. For your protection, carefully package the product for shipment and insure it with the carrier. Be sure to enclose the following items with your appliance: any accessories related to your problem; your full return address and daytime phone number; a note describing the problem you experienced; a copy of your sales receipt or other proof of purchase to determine warranty sta-

copy of your sales receipt or other proof of purchase to determine warranty status. C.O.D. shipments cannot be accepted.

Return the appliance to:

ATTN: Repair Department, Salton, Inc. 708 South Missouri St. Macon, MO 63552

For more information on Salton/MAXIM products:

visit our website: http://www.salton-maxim.com, or you can email us at: salton@saltonusa.com

Printed in China © 2000 Salton, Inc.

P/N# 60607