


OWNER'S MANUAL

Model No. KE5

AQUA PRESTO!

HOT WATER DISPENSER



salton®

Get a taste of the good life with Salton.

Important Safeguards


When using electrical appliances, basic safety precautions should always be followed:

1. Read all instructions.
2. Do not touch hot surfaces. Use handles or knobs.
3. To protect against fire, electric shock and injury to persons, do not immerse cord, plugs or any portion of the main body in water or other liquids.
4. Close supervision is necessary when any appliance is used by or near children.
5. Unplug from the outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts and before cleaning the appliance.
6. Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner. Return to Salton Maxim Housewares, Inc. for examination, repair or adjustment.
7. The use of accessory attachments not recommended by Salton Maxim Housewares, Inc. may result in fire, electrical shock or injury to persons.
8. Do not use outdoors.
9. Do not let cord hang over edge of table or counter or touch hot surfaces.
10. Do not place on or near a hot gas or electric burner or in a heated oven.
11. Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "OFF"; then remove plug from wall outlet.
12. Do not use appliance for other than intended household use.
13. Scalding may occur if lid is opened during the boiling cycle.
14. During all operations, always make sure that the lid is closed and secured.


THIS APPLIANCE IS FOR HOUSEHOLD USE ONLY

Save These Instructions

Getting To Know Your Salton® KE5 AQUA PRESTO!



1. Pump Lock
2. Lid Latch
3. Spout
4. Water Level Indicator Window
5. Boil Indicator Light
6. Keep Warm Indicator Light
7. Pump Pressure Plate
8. Handle
9. Plug Receptacle
10. Detachable Cord



Short Cord Instructions

A short power-supply cord is provided to reduce the risk resulting from becoming entangled in or tripping over a longer cord.

An extension cord should be a grounding type three conductor design that has an electrical rating at least as great as the appliance on which it is used.

Operating Instructions

Before using your Salton® **AQUA PRESTO!**, fill it to the maximum capacity and boil the water. Follow directions below and discard the boiled water. This process will clean away any residue which has built up from shipping.

1. Open lid by releasing the latch.
2. Fill water to the maximum level marked on the Water Level Indicator Window.

CAUTION: Overfilling will prevent the water to heat and boil in a timely manner and may cause damage to the pot.

3. Plug electrical cord into the plug receptacle and then into the wall outlet.
4. At this time the **Boil** Indicator Light will illuminate. The water will begin to heat and eventually boil.
5. After boiling, the **Keep Warm** Indicator Light will illuminate. The water will then maintain its heat at approximately 200° F.
6. The unit will occasionally switch to '**HEATING**' to indicate the water is being maintained at the correct temperature, particularly when more cold water has been added.
7. To dispense hot water, place a cup under the Spout; slide the Pump Lock to "Unlock" position and then press the Pump Pressure Plate. The water will automatically pour out from the Spout when the Pump Pressure Plate is pushed.
8. To dispose of remaining water, allow the pot to cool completely. Once cooled you may remove the lid from the unit by pulling forward and releasing it from its hinge. Empty the water over a sink.

Care & Cleaning

1. Unplug the unit and wait for it to cool completely before cleaning.
2. Wipe exterior with a damp cloth or sponge.
3. Wipe the inside of the kettle with a sponge or soft clean cloth soaked in lukewarm water with a mild detergent. Rinse and dry thoroughly.
4. Do not use harsh abrasive cleaners as they may scratch the surface and/or interior of the kettle.

ONE-YEAR LIMITED WARRANTY

This Salton/MAXIM product warranty extends to the original consumer purchaser of the product.

Warranty Duration: This product is warranted to the original consumer purchaser for a period of one (1) year from the original purchase date.

Warranty Coverage: This product is warranted against defective materials or workmanship. This warranty is void if the product has been damaged by accident, in shipment, unreasonable use, misuse, neglect, improper service, commercial use, repairs by unauthorized personnel or other causes not arising out of defects in materials or workmanship. This warranty is effective only if the product is purchased and operated in the USA, and does not extend to any units which have been used in violation of written instructions furnished by Salton/MAXIM Housewares, Inc., or to units which have been altered or modified or to damage to products or parts thereof which have had the serial number removed, altered, defaced or rendered illegible.

Warranty Disclaimers: This warranty is in lieu of all warranties expressed or implied and no representative or person is authorized to assume for Salton/MAXIM Housewares, Inc. any other liability in connection with the sale of our products. There shall be no claims for defects or failure of performance or product failure under any theory of tort, contract or commercial law including, but not limited to, negligence, gross negligence, strict liability, breach of warranty and breach of contract.

Warranty Performance: During the above one-year warranty period, a product with a defect will be either repaired or replaced with a reconditioned comparable model (at Salton/MAXIM's option) when the product is returned to the Salton/MAXIM facility. The repaired or replacement product will be in warranty for the balance of the one-year warranty period and an additional one-month period. No charge will be made for such repair or replacement.

Service and Repair

Should the appliance malfunction, you should first call toll-free 1-800-233-9054 between the hours of 9:00 am and 5:00 pm Central Standard Time and ask for CUSTOMER SERVICE stating that you are a consumer with a problem.

In-Warranty Service: For an appliance covered under the warranty period, no charge is made for service or postage. Call for pre-paid return mailing label. (U.S. Customers Only)

Out-of Warranty Service: A flat rate charge by model is made for out-of-warranty service. Include \$8.00 for return shipping and handling.

Salton/MAXIM cannot assume responsibility for loss or damage during incoming shipment. For your protection, carefully package the product for shipment and insure it with the carrier. Be sure to enclose the following items with your appliance: any accessories related to your problem; your full return address and daytime phone number; a note describing the problem you experienced; a copy of your sales receipt or other proof of purchase to determine warranty status. C.O.D. shipments cannot be accepted.

Return the appliance to:

ATTN: Repair Department, Salton/Maxim Housewares, Inc.
550 Business Center Drive, Mt. Prospect, Illinois 60056

For more information on Salton/MAXIM products:

visit our website: URL <http://www.salton-maxim.com> or
E-mail us at SALTON 550 @ aol.com

Printed in China

© 1997 Salton/MAXIM Housewares, Inc.