


RELAXOR[®]



Facial Brush WITH STORAGE CASE

OWNER'S MANUAL &
OPERATING INSTRUCTIONS


Model FB8PBX

SPA THERAPY™

OPERATING INSTRUCTIONS

INSTALLING BATTERIES

Remove Battery Chamber Cover located at the lower end of the Handle, insert two AA batteries and replace Cover. Refer to diagram inside Chamber for correct battery placement.



ATTACHMENTS

Select the Attachment you would like to use. Make sure the unit is OFF before snapping Attachment into place.

Make sure the unit is OFF before removing Attachment. To remove, pull Attachment firmly away from the unit's body.

CLEANSING BRUSH

Used for intensive and soothing facial cleaning.

1. Remove excess make-up.
2. Apply soap or a cleansing cream to the Brush.
3. Activate Facial Salon by pressing the ON Button indicated by the "O" and apply Brush to face, avoiding the sensitive areas near the eyes.
4. Drive the Brush gently in a circular direction, starting at the center of the face and working outward.
5. When finished, deactivate Facial Salon by pressing the OFF Button indicated by the "I" and rinse face with warm water or toner.

MASSAGING ROLLER

The Massaging Roller is used to apply your favorite moisturizer.

- 1. Apply moisturizer directly to face.*
- 2. Activate Facial Salon and massage face using gentle upward and circular strokes. Do not massage for more than two minutes and avoid the sensitive areas near the eyes.*
- 3. When finished, deactivate Facial Salon by pressing the OFF Button indicated by the "I" and rinse face with warm water.*

SPONGE APPLICATOR

The Sponge Applicator will help you achieve a smooth and even finish to your foundation.

- 1. Activate Facial Salon and massage face using gentle upward and circular strokes. Do not use Sponge Applicator for more than two minutes. Avoid the sensitive areas near the eyes.*
- 2. When finished, deactivate Facial Salon by pressing the OFF Button indicated by the "I" and rinse face with warm water.*

CLEANING INSTRUCTIONS

- 1. Wipe Facial Salon occasionally with a dampened cloth.*
- 2. Rinse Brush and Sponge with warm water after every use.*
- 3. Rinse out lotions and creams from Massaging Roller.*

CAUTION:

- 1. Do not press too hard with the Facial Salon as this could slow down the motor and could possibly hurt sensitive skin.*
- 2. Do not wash or immerse the Main Body in water or any other liquid. Unit is not waterproof.*
- 3. Press the OFF Button indicated by the "I" to turn off the unit before changing Attachments.*
- 4. Do not leave dead batteries in the battery chamber for long periods of time. If batteries leak they could damage unit's internal components.*
- 5. Do not open Battery Chamber in water or when the appliance is wet.*
- 6. Snap the desired Attachment into place by pressing gently until it clicks into place.*
- 7. Do not use in areas of severe ache, pains or skin abrasion.*
- 8. Avoid lip and eye areas.*

LIMITED ONE YEAR WARRANTY

Warranty: This Relaxor® product is warranted by Salton, Inc. to be free from defects in materials or workmanship for a period of (1) year from the original purchase date. This product warranty covers only the original consumer purchaser of the product.

Warranty Coverage: This warranty is void if the product has been damaged by accident in shipment, unreasonable use, misuse, neglect, improper service, commercial use, repairs by unauthorized personnel, normal wear and tear, improper assembly, installation or maintenance abuse or other causes not arising out of defects in materials or workmanship. This warranty is effective only if the product is purchased and operated in the USA, and does not extend to any units which have been used in violation of written instructions furnished by with the product or to units which have been altered or modified or to damage to products or parts thereof which have had the serial number removed, altered, defaced or rendered illegible.

Implied Warranties: ANY IMPLIED WARRANTIES WHICH THE PURCHASER MAY HAVE ARE LIMITED IN DURATION TO ONE (1) YEAR FROM THE DATE OF PURCHASE. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.

Warranty Performance: During the above one-year warranty period, a product with a defect will be either repaired or replaced with a reconditioned comparable model (at our option) when the product is returned to the Repair Center, or the purchase price refunded. The repaired or replacement product will be in warranty for the balance of the one-year warranty period and an additional one-month period. No charge will be made for such repair or replacement.

Service and Repair: Should the appliance malfunction, you should first call toll-free 1 (800) 233-9054 between the hours of 9:00 am and 5:00 pm Central Standard Time and ask for CONSUMER SERVICE stating that you are a consumer with a problem. Please refer to model number: FB8PBX when you call.

In-Warranty Service (USA): For an appliance covered under the warranty period, no charge is made for service or postage. Call for return authorization 1 (800) 233-9054.

Out-of Warranty Service: A flat rate charge by model is made for out-of-warranty service. Include \$6.00 (U.S.) for return shipping and handling. We will notify you by mail of the amount of the charge for service and require you to pay in advance for the repair or replacement.

For Products Purchased in the USA, but Used in Canada: You may return the product insured, packaged with sufficient protection, and postage and insurance prepaid to the USA address listed below. Please note that all customs duty / brokerage fees, if any, must be paid by you and we will require you to pay the cost of customs duty / brokerage fees to us in advance of our performing any service.

Risk During Shipment: We cannot assume responsibility for loss or damage during incoming shipment. For your protection, carefully package the product for shipment and insure it with the carrier. Be sure to enclose the following items with your appliance: any accessories related to your problem, your full return address and daytime phone number, a note describing the problem you experienced, a copy of your sales receipt or other proof of purchase to determine warranty status. C.O.D. shipments cannot be accepted.

To return the appliance, ship to:

ATTN: Repair Center
Salton, Inc.
708 South Missouri Street
Macon, MO 63552

To contact us, please write to, call, or email:

Salton, Inc.
P.O. Box 1637
Columbia, MO 65205-1637
1-800-233-9054
E-mail: Salton@Saltonusa.com

Limitation of Remedies: No representative or person is authorized to assume for Salton, Inc. any other liability in connection with the sale of our products. There shall be no claims for defects or failure of performance or product failure under any theory of tort, contract or commercial law including, but not limited to negligence, gross negligence, strict liability, breach of warranty and breach of contract. Repair, replacement or refund shall be the sole remedy of the purchaser under this warranty, and **in no event shall Salton be liable for any incidental or consequential damages, losses or expenses.** Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

Legal Rights: This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

For more information on Salton products: visit our website: www.eSalton.com

©2002 Salton, Inc. All rights reserved.

Made in China

P/N 61185

11/02