


OWNER'S MANUAL
MODEL No. NT-10

Personal Trimmer



salton[®]

Get a taste of the good life with Salton.



Before using small electric appliances, basic safety precautions should always be followed, including the following:


1. Read all instructions carefully.
2. Use the Personal Trimmer for ears and nose only for its intended use as described in this manual.
3. **WARNING!** *To avoid injury, never use the Personal Trimmer for ears and nose to trim facial hair, body hair, hair on ~~one~~ one's head or eyelashes.*
4. **WARNING!** *Never use the Personal Trimmer for ears and nose to remove debris from nose and ears. This item is designed and intended to only trim nose and ear hair.*
5. Close supervision is necessary when this appliance is used on or near invalids or children. *We do not recommend using this appliance on children.*
6. **WARNING!** *To avoid injury, do not use the Personal Trimmer for ears and nose if the blade or blade holder are broken or damaged in any way.*
7. **WARNING!** *Do not use your Personal Trimmer for ears and nose when you have scars, scabs or blemishes inside nose or ears.*
8. **WARNING!** *To avoid injury, always use the stopper when removing hairs from your ears or nose.*
9. **CAUTION:** *To avoid damaging the blades, do not allow the blade to come in contact with hard objects.*
10. **CAUTION:** *Do not use while bathing or in shower. Do not immerse the unit in water or any other liquids.*

SAVE THESE INSTRUCTIONS

Personal Trimmer for Ears and Nose

Before using your Personal Trimmer for ears and nose for the first time, become familiar with all of its parts.

1. Blade
2. Blade Cover
3. Stopper
4. Stopper Guide Slot
5. Blade Holder
6. On/Off Switch
7. Battery Compartment (underneath)
8. Cleaning Brush



Operating Instructions

Battery Installation

1. Remove the battery compartment cover and place one AA size battery in the position indicated inside the battery compartment.
We recommend the use of alkaline batteries.
2. Replace the battery compartment cover.

How to Use Your Personal Trimmer for Ears and Nose

1. Slide the stopper attachment over the blade. The upper position is for a shallow trim. The lower position is for a deep trim.
2. Switch on the appliance by sliding the On/Off switch upwards.
Slowly guide the blade to the area you want to trim.
3. Switch off after each use.

Care and Maintenance

1. This appliance is for household use only.
2. Make sure the switch is in the "OFF" position before you clean the blade with the brush provided.
3. Clean the unit with a damp cloth.
4. Avoid dropping the appliance and keep it away from water, heat source, flame or chemicals.
5. Remove the battery from the unit if it will not be used for an extended period of time.

LIMITED WARRANTY

Products distributed by Salton/MAXIM Housewares, Inc. are warranted for one year from date of purchase against defects in workmanship and material. During that period these defects will be repaired or the product will be replaced at Salton/MAXIM's option, without charge. This warranty covers normal consumer usage and does not cover damage which occurs in shipment or failure which results from alteration, accident, misuse, abuse, neglect, installation, commercial use or improper maintenance. This warranty is effective only if the product is purchased and operated in the USA, and does not extend to any units which have been used in violation of written instructions furnished by Salton/MAXIM Housewares, Inc., or to units which have been altered or modified without authorization of Salton/MAXIM Housewares, Inc., or to damage to products or parts thereof which have had the serial number removed, altered, defaced or rendered illegible. This warranty does not cover damage which results from unauthorized repairs.

Service and Repair

DO NOT attempt to repair your SALTON® NT-10 Personal Trimmer. Attempts to repair this appliance yourself may render it dangerous to use. Should the appliance malfunction, you should first call our CONSUMER SERVICE DEPARTMENT toll free at 1-800-233-9054 Mon.-Fri. between the hours of 9:00 am and 5:00 pm Central Standard Time, stating that you are a consumer with a problem. If the problem cannot be resolved, you will be asked to return the appliance to the factory for repair. Under no circumstances should you attempt to open the housing and repair the appliance. Should you do this, your warranty will be voided.

To Return for Service

1. Securely package and return the product, PREPAID to:
Salton/MAXIM Housewares, Inc., Repair Department
550 Business Center Drive, Mt. Prospect, IL 60056
 2. Be sure to enclose:
 - a. Your name, address and phone number.
 - b. The date of purchase (or receipt as a gift).
 - c. An explanation of the malfunction or reason for return.
 - d. Eight dollars (\$8.00) Check or Money Order payable to Salton/MAXIM Housewares, Inc. for return postage and handling.
 - e. To insure prompt "In-Warranty" service, be sure to include proof of date of purchase.
- We recommend you take the necessary precaution of insuring the parcel.
3. Toll Free Number: 1-800-233-9054.



salton®