


OWNER'S MANUAL
Model No. KM17

10-Cup Coffeemaker



salton®

Important Safeguards

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of electric shock, and/or injury to persons, including the following:

1. Read all instructions before using this machine.
2. Do not touch hot surfaces. Use handles or knobs.
3. To protect against electrical hazards, do not immerse cord, plugs, or machine in water or other liquid.
4. Close supervision is necessary when this appliance is used by near children.
5. Turn Control Switch to "OFF" and unplug from outlet when coffeemaker is not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
6. Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions, or has been damaged in any manner. Return appliance to Salton/MAXIM Housewares, Inc. for examination, repair or adjustment.
7. The use of accessory attachments not evaluated for use with this appliance, or sold by Salton®/MAXIM Housewares, Inc. may cause hazards or injuries.
8. Do not use outdoors.
9. Do not let cord hang over edge of table or counter or touch hot surfaces.
10. Do not place this appliance on or near a hot gas or electric burner, or in a heated oven.
11. To disconnect, turn any control to "OFF", then remove plug from wall outlet.
12. Do not use appliance for other than intended household use.
13. **Carafe Use and Care:**
 - Breakage may occur if the following instructions are not followed:***
 - a. This Carafe is designed for use with your coffeemaker and therefore must ***never*** be used on a rangetop or in any oven, ***including a microwave.***
 - b. Do not set a hot Carafe on a wet or cold surface.
 - c. Do not use a cracked Carafe or a Carafe having a loose or weakened handle.
 - d. Do not clean the Carafe with cleansers, steel wool pads, or other abrasive materials.
 - e. Discard Carafe immediately if it is ever boiled dry.
 - f. Avoid sharp blows, scratches or rough handling.
14. **WARNING: To reduce the risk of fire or electric shock, do not remove any service covers.** No user serviceable parts inside. Repair should be performed by authorized personnel only.

THIS APPLIANCE IS FOR HOUSEHOLD USE ONLY

Save These Instructions

Short Cord Instructions

A short power-supply cord is provided to reduce the risk resulting from becoming entangled in or tripping over a longer cord.

Longer detachable power-supply cords or extension cords are available and may be used if care is exercised in their use.

If a longer detachable power-supply cord or extension cord is used, (1) the marked electrical rating of the extension cord should be at least 10 amps and 120 volts and (2) the longer cord should be arranged so that it will not drape over the counter top or table top where it can be pulled on by children or tripped over accidentally.


Polarized Plug

This appliance has a polarized plug (one blade is wider than the other): To reduce the risk of electric shock, this plug is intended to fit into a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to modify the plug in any way.

Introduction

Please read all of the instructions carefully before you begin to use this appliance. Proper care and maintenance will ensure the long life of this coffeemaker and its trouble-free operation. Save these instructions and refer to them often for cleaning and care tips.

Getting to Know Your Salton® 10 Cup Coffeemaker



- 1. Filter Basket
- 2. Water Reservoir
- 3. Warmer Plate

- 4. Control Switch
- 5. Carafe

IMPORTANT! CLEAN YOUR COFFEEMAKER BEFORE USING FOR THE FIRST TIME!

Wash Carafe, lid and removable Filter Basket in mild detergent and water. Rinse each thoroughly. Follow steps 4 through 6 below (with water only) to clean the inside of your coffeemaker.

Brewing Coffee

1. Slide the Filter Basket open and insert a paper filter into the Filter Basket.
2. Add the desired amount of coffee according to the coffee measurement chart on the following page. Shake lightly to level coffee.
3. Be sure the paper filter is properly centered before sliding the Filter Basket into place.
4. Fill the Carafe with tap water to desired level as marked on the side of the Carafe. (1 cup equals 8 ounces.)
5. Pour the water into the Water Reservoir. Place the empty Carafe into the Warmer Plate.
6. Turn your coffeemaker switch "ON." When coffee stops flowing, the brewing cycle is complete.
7. Carefully remove the Filter Basket and discard the used grounds and filter. Rinse the Filter Basket and replace.
8. To make another pot of coffee, repeat Steps 1 through 7.
9. Be sure to turn your coffeemaker "OFF" when the Carafe is empty and you are no longer using your coffeemaker. Unplug the power cord when using the coffeemaker.

WARNING! To avoid risk of personal injury or damage to property as a result of overflow, be sure that the Carafe is squarely centered under the brew basket during brewing cycle.

WARNING! BREWED COFFEE AND GROUNDS, BOTH IN BREW BASKET AND CARAFE ARE VERY HOT. HANDLE WITH CARE TO AVOID SCALDING.

IF BREW BASKET OVERFLOWS, OR IF BREW BASKET FAILS TO DRAIN INTO CARAFE DURING BREW CYCLE, DO NOT OPEN OR HANDLE BASKET. UNPLUG THE COFFEEMAKER, AND WAIT FOR CONTENTS TO COOL BEFORE HANDLING!

SUGGESTED COFFEE MEASUREMENT

For the best results, use drip grind recommended for automatic drip coffeemakers.

TO BREW	GROUND COFFEE
10 cups	9 tablespoons or 4-1/2 scoops
10 cups	7 tablespoons or 3-1/2 scoops
10 cups	6 tablespoons or 3 scoops
10 cups	5 tablespoons or 2-1/2 scoops
10 cups	3 tablespoons or 1-1/2 scoops

*Use more or less coffee to suit your taste.

2 level Tablespoons = 1 level scoop

1 cup = 8 oz. brewed coffee

Cleaning Instructions

When you begin to notice excessive steaming, or the if brewing time increases considerably, or if the pumping action stops before all the water has been pumped out of the machine, your coffeemaker then the appliance requires cleaning.

This condition is caused by a buildup of lime and mineral deposits from your water. The frequency of cleaning depends on the hardness of water used. The following table gives the suggested cleaning intervals.

SUGGESTED CLEANING INTERVAL

Type of Water	Cleaning Frequency
Soft Water	every 80 brew cycles
Hard Water	every 40 brew cycles

Cleaning Instructions *(continued)*

1. Pour one quart of undiluted white household vinegar into your coffeemaker.
2. Place a paper filter into the Filter Basket and slide the Filter Basket into place.
3. Place the empty Carafe on the Warming Plate and turn the coffeemaker "ON". When three cups have flowed through, turn the coffeemaker "OFF" and let stand for 1/2 hour.
4. After 1/2 hour, pour the vinegar back into the coffeemaker.
5. Place the empty Carafe on the Warming Plate. Turn the coffeemaker "ON" and let all of the vinegar flow through.
6. Discard the vinegar and the paper filter.
7. To flush out all traces of vinegar, pour a Carafe full of tap water into the coffeemaker, turn it "ON" and allow it all to cycle through.
8. Discard the water and turn the coffeemaker "OFF." Repeat steps 7 and 8.

Carafe Cleaning

Hard water can leave a whitish mineral deposit inside the Carafe. Coffee and tea discolor these deposits, sometimes leaving a brownish stain inside the Carafe. To remove these stains, follow these simple steps:

1. Use a solution of equal parts of white vinegar and hot water.
2. Let solution stand in Carafe for about 20 minutes and then discard.
3. Wash and rinse the Carafe thoroughly using a soft cloth. Do not use harsh, abrasive cleaners. These may cause scratches which can lead to breakage.
4. **Do not wash in dishwasher.**

IMPORTANT NOTICE

*If any parts are missing or defective,
DO NOT return this product.*

Please call our Customer Service Department for assistance.

800-233-9054 Monday - Friday 9am - 5pm CST

Thank You

ONE-YEAR LIMITED WARRANTY

This Salton/MAXIM product warranty extends to the original consumer purchaser of the product.

Warranty Duration: This product is warranted to the original consumer purchaser for a period of one (1) year from the original purchase date.

Warranty Coverage: This product is warranted against defective materials or workmanship. This warranty is void if the product has been damaged by accident, in shipment, unreasonable use, misuse, neglect, improper service, commercial use, repairs by unauthorized personnel or other causes not arising out of defects in materials or workmanship. This warranty is effective only if the product is purchased and operated in the USA, and does not extend to any units which have been used in violation of written instructions furnished by Salton/MAXIM Housewares, Inc., or to units which have been altered or modified or to damage to products or parts thereof which have had the serial number removed, altered, defaced or rendered illegible.

Warranty Disclaimers: This warranty is in lieu of all warranties expressed or implied and no representative or person is authorized to assume for Salton/MAXIM Housewares, Inc. any other liability in connection with the sale of our products. There shall be no claims for defects or failure of performance or product failure under any theory of tort, contract or commercial law including, but not limited to, negligence, gross negligence, strict liability, breach of warranty and breach of contract.

Warranty Performance: During the above one-year warranty period, a product with a defect will be either repaired or replaced with a reconditioned comparable model (at Salton/MAXIM's option) when the product is returned to the Salton/MAXIM facility. The repaired or replacement product will be in warranty for the balance of the one-year warranty period and an additional one-month period. No charge will be made for such repair or replacement.

Service and Repair

Should the appliance malfunction, you should first call toll-free 1-800-233-9054 between the hours of 9:00 am and 5:00 pm Central Standard Time and ask for CUSTOMER SERVICE stating that you are a consumer with a problem.

In-Warranty Service (USA) for an appliance covered under the warranty period, no charge is made for service or postage. Call for pre-paid return mailing label. (U.S. Customers Only)

In-Warranty Service (Canada) for an appliance covered under the warranty period, no charge is made for service or postage. Please return the product insured, packaged with sufficient protection, and postage and insurance prepaid to the address listed below. Customs duty/brokerage fee, if any, must be paid by the consumer.

Out-of Warranty Service: A flat rate charge by model is made for out-of-warranty service. Include \$6.00 (U.S.) for return shipping and handling.

Salton/MAXIM cannot assume responsibility for loss or damage during incoming shipment. For your protection, carefully package the product for shipment and insure it with the carrier. Be sure to enclose the following items with your appliance: any accessories related to your problem; your full return address and daytime phone number; a note describing the problem you experienced; a copy of your sales receipt or other proof of purchase to determine warranty status. C.O.D. shipments cannot be accepted.

Return the appliance to:

ATTN: Repair Department, Salton/Maxim Housewares, Inc.
550 Business Center Drive, Mt. Prospect, Illinois 60056

For more information on Salton/MAXIM products:

visit our website: URL <http://www.salton-maxim.com> or
E-mail us at SALTON 550 @ aol.com