

Model MW5DT

Desktop Cafe
Mug Warmer

OWNER'S MANUAL

Important Safeguards

When using your *Desktop Cafe Mug Warmer* or any electrical appliance, these basic safety precautions should be followed, including the following:

1. Read all instructions.
2. Do not touch hot surfaces. Handle by plastic sides only.
3. To protect against electrical hazard, do not immerse cord, plug or base unit in water or other liquid.
4. Close supervision is necessary when any appliance is used by or near children.
5. Unplug from outlet and allow to cool before cleaning.
6. Never operate any appliance with a damaged cord set or plug, or after the appliance malfunctions, or is dropped or damaged in any manner. Return the appliance to Salton/MAXIM Housewares, Inc. for examination, repair or electrical/mechanical adjustment.
7. The use of accessories or attachments not recommended by Salton/MAXIM may cause fire, electrical shock or injury.
8. Do not use outdoors. This product is for household use only.
9. Do not let cord hang over edge of table or counter, or touch hot surfaces.
10. Do not place on or near a hot gas or electric burner, or in a heated oven.
11. Do not move appliance when supporting a container of hot liquids.
12. To disconnect, turn the control to "OFF." Then remove the plug from wall outlet.
13. Do not use appliance for other than intended use.
14. To reduce risk of injury, DO NOT drape cord over the counter top or tabletop where it can be pulled on by children or tripped over unintentionally.

Save These Instructions

FOR HOUSEHOLD USE ONLY

Polarized Plug

If this appliance has a polarized plug (one blade is wider than the other): To reduce the risk of electric shock, this plug is intended to fit into a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to modify the plug in any way.

Short Cord Instructions

A short power-supply cord (or detachable power-supply cord) is provided to reduce the risk resulting from becoming entangled in or tripping over a longer cord.

Longer detachable power-supply cords or extension cords are available and may be used if care is exercised in their use.

If a longer detachable power-supply cord or extension cord is used, (1) the marked electrical rating of the extension cord should be at least as great as the electrical rating of the appliance, and (2) the longer cord should be arranged so that it will not drape over the counter top or table top where it can be pulled on by children or tripped over unintentionally.

Instructions For Use

Your *Desktop Cafe Mug Warmer* is designed to keep a cup of hot coffee, soup or other beverages at perfect drinking temperature. It is not intended to heat a cold cup of coffee, only to maintain a drinking temperature.

The *Desktop Cafe Mug Warmer* has a switch to turn the unit on and off. Slide the switch to "OFF" position when not in use.

Use with your favorite cup . . . any china, glass or ceramic. ***The Desktop Cafe Mug Warmer is not intended for use with plastic or styrofoam cups.***

Care and Cleaning

Your *Desktop Cafe Mug Warmer* requires very little care and cleaning. Before cleaning, make sure the unit is disconnected and cold to the touch. Periodically, wipe the surface of the unit with a damp cloth or sponge. To remove stubborn soil, use a mild, non-abrasive cleaner.

ONE-YEAR LIMITED WARRANTY

This Salton/MAXIM product warranty extends to the original consumer purchaser of the product.

Warranty Duration: This product is warranted to the original consumer purchaser for a period of one (1) year from the original purchase date.

Warranty Coverage: This product is warranted against defective materials or workmanship. This warranty is void if the product has been damaged by accident, in shipment, unreasonable use, misuse, neglect, improper service, commercial use, repairs by unauthorized personnel or other causes not arising out of defects in materials or workmanship. This warranty is effective only if the product is purchased and operated in the USA, and does not extend to any units which have been used in violation of written instructions furnished by Salton/MAXIM Housewares, Inc., or to units which have been altered or modified or to damage to products or parts thereof which have had the serial number removed, altered, defaced or rendered illegible.

Warranty Disclaimers: This warranty is in lieu of all warranties expressed or implied and no representative or person is authorized to assume for Salton/MAXIM Housewares, Inc. any other liability in connection with the sale of our products. There shall be no claims for defects or failure of performance or product failure under any theory of tort, contract or commercial law including, but not limited to, negligence, gross negligence, strict liability, breach of warranty and breach of contract.

Warranty Performance: During the above one-year warranty period, a product with a defect will be either repaired or replaced with a reconditioned comparable model (at Salton/MAXIM's option) when the product is returned to the Salton/MAXIM facility. The repaired or replacement product will be in warranty for the balance of the one-year warranty period and an additional one-month period. No charge will be made for such repair or replacement.

Service and Repair

Should the appliance malfunction, you should first call toll-free 1-800-233-9054 between the hours of 9:00 am and 5:00 pm Central Standard Time and ask for CONSUMER CUSTOMER SERVICE stating that you are a consumer with a problem.

In-Warranty Service: For an appliance covered under the warranty period, no charge is made for service or postage. Call for pre-paid return mailing label. (U.S. Customers Only)

Out-of Warranty Service: A flat rate charge by model is made for out-of-warranty service. Include \$6.00 for return shipping and handling.

Salton/MAXIM cannot assume responsibility for loss or damage during incoming shipment. For your protection, carefully package the product for shipment and insure it with the carrier. Be sure to enclose the following items with your appliance: any accessories related to your problem; your full return address and daytime phone number; a note describing the problem you experienced; a copy of your sales receipt or other proof of purchase to determine warranty status. C.O.D. shipments cannot be accepted.

Return the appliance to:

ATTN: Repair Department
Salton/Maxim Housewares, Inc.
550 Business Center Drive
Mt. Prospect, Illinois 60056

For more information on Salton /MAXIM products:
visit our web site: <http://www.salton-maxim.com> or
e-mail us at salton550@aol.com