


# Relaxon®



## 6 MASSAGE MOTORS WITH SOOTHING HEAT

### OWNER'S MANUAL & OPERATING INSTRUCTIONS

Model SEAT6

SEAT TOPPER

# IMPORTANT SAFEGUARDS

When using your RELAXOR® SEAT TOPPER, basic safety precautions should always be followed, including the following:

1. Read all instructions before using.

**DANGER!** To reduce risk of electric shock:

1. Always unplug the product from the electrical outlet immediately after using and before cleaning.
2. Do not reach for a product that has fallen into water. Unplug immediately.
3. Do not use while bathing or in a shower.

**WARNING! OPERATE YOUR SYSTEM ACCORDING TO THIS MANUAL. USE ONLY THE POWER DEVICE SUPPLIED.**


To reduce risk of burns, fire, electric shock, or injury to persons:

1. Your RELAXOR® product should never be left unattended when plugged in. Unplug from outlet when not in use, and before putting on or taking off parts.
2. Use this product only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.
3. Never operate the RELAXOR® product if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water. Contact Consumer Service for instructions on returning it for examination and repair.
4. Close supervision is necessary when this product is used by, on, or near children or disabled persons.
5. Do not use outdoors.
6. Keep the cord away from heated surfaces.
7. Do not operate where aerosol (spray) products are being used or where oxygen is being administered.
8. Use heated surfaces carefully. May cause serious burns. Do not use heated surfaces over sensitive skin areas or in the presence of poor circulation.
9. If you are under a physician's care and/or have a condition requiring the use of any medical device, please consult your health care provider prior to using this product.

## SAVE THESE INSTRUCTIONS FOR HOUSEHOLD USE ONLY


# CONTROL WAND

1. POWER
2. MESSAGE  
STYLE
3. MESSAGE  
PATTERN
4. ISOLATE
5. SELECT
6. INTENSITY
7. SPEED
8. HEAT



MESSAGE  
MOTOR  
INDICATOR  
LED's


HEAT  
(Red)



TRANSFORMER  
P/N 10071



DC CAR ADAPTER  
P/N 10072




## OPERATING INSTRUCTIONS

1. The Control Wand is permanently attached.
2. Plug the cord from the Transformer into the receptacle on the bottom of the Control Wand. Plug Transformer into an AC electrical outlet, and then plug the Transformer into the electrical wall outlet. If you are using your Seat Topper in the car then plug the DC Car Adaptor into your vehicle's cigarette lighter.
3. Place your Seat Topper on a sturdy and comfortable surface.
4. Sit on your Seat Topper and study the Control Wand diagram and instructions to familiarize yourself with the System operation.

**NOTE:** The Seat Topper will automatically shut down after approximately 15 minutes of operation. To restart, simply press the POWER Button again to restart the unit.

**NOTE:** It is normal for the Control Wand to become warm during use.

## MASSAGE MOTOR PLACEMENT



# CONTROL WAND INSTRUCTIONS

1.

## POWER:

Press the **POWER** Button to activate the unit.

2.

## MESSAGE STYLE:

**PULSE:** This is the default pattern.

The *Massage Motors* pulse at a gentle throbbing intensity.

**TAPPING:** *Massage Motors* quickly, but strongly, deliver a tapping sensation

**KNEADING:** *Massage Motors* pulse at a gently decreasing intensity

**WAVE:** *Massage Motors* gradually increase and then decrease intensity.

3.

## MESSAGE PATTERN:

*Massage pattern* controls which of the 6 motors are activated, in what combination, and in what sequence.

**PATTERN 1:** (Default Pattern)

1>2>3>4>5, 6>5, 6...

**PATTERN 2:**

1, 2>3, 4>5, 6>5, 6...

**PATTERN 3:**

1, 2, 3, 4>3, 4, 5, 6>1, 2, 5, 6>1, 2, 3, 4...

**PATTERN 4:**

1, 2, 3, 4>5, 6>5, 6>1, 2, 3, 4...

4.

## ISOLATE:

To focus the message on a specific area press the **ISOLATE** Button.

5.

## SELECT:

To select a different *Massage Motor* or set of *Motors* while using the **ISOLATE** feature, press the **SELECT** Button.

6.

## INTENSITY:

Controls the strength of the *Massage*. Press the **INTENSITY** Button to choose from 3 intensity levels.

7.

## SPEED:

Controls the speed of the *Massage*. Press the **SPEED** Button to choose from 3 speeds.

8.

## HEAT:

To add heat to your *massage*, press the **HEAT** Button.

The red LED will illuminate. Press the **HEAT** Button again to deactivate.

## REPLACING THE FUSE

*The fuse in the Car Adapter is replaceable. To replace:*

- 1. Unscrew the Cap.*
- 2. Remove the Spring and Fuse.*
- 3. Replace the Fuse with a standard 3 amp Fuse.*
- 4. Replace Spring.*
- 5. Replace Cap.*

## USER MAINTENANCE INSTRUCTIONS

*No user maintenance of this product is required. If the Seat Topper does not function, be sure...*

- (a) The Adaptor is plugged into an electrical outlet.*
- (b) The Adaptor cord is plugged into, and fully engaged, in the receptacles.*

*If there is a malfunction of any kind, contact Consumer Service for instructions on returning it for examination and repair.*

### CLEANING

*You may clean the Seat Topper with a damp cloth and warm water.*

*DO NOT SATURATE. Allow adequate time to dry.*

### STORAGE

*Store the Seat Topper in its box or in a clean dry place..*

## LIMITED ONE YEAR WARRANTY

**Warranty:** This Relaxor® product is warranted by Salton, Inc. to be free from defects in materials or workmanship for a period of (1) year from the original purchase date. This product warranty covers only the original consumer purchaser of the product.

**Warranty Coverage:** This warranty is void if the product has been damaged by accident in shipment, unreasonable use, misuse, neglect, improper service, commercial use, repairs by unauthorized personnel, normal wear and tear, improper assembly, installation or maintenance abuse or other causes not arising out of defects in materials or workmanship. This warranty is effective only if the product is purchased and operated in the USA, and does not extend to any units which have been used in violation of written instructions furnished by with the product or to units which have been altered or modified or to damage to products or parts thereof which have had the serial number removed, altered, defaced or rendered illegible.

**Implied Warranties:** ANY IMPLIED WARRANTIES WHICH THE PURCHASER MAY HAVE ARE LIMITED IN DURATION TO ONE (1) YEAR FROM THE DATE OF PURCHASE. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.

**Warranty Performance:** During the above one-year warranty period, a product with a defect will be either repaired or replaced with a reconditioned comparable model (at our option) when the product is returned to the Repair Center, or the purchase price refunded. The repaired or replacement product will be in warranty for the balance of the one-year warranty period and an additional one-month period. No charge will be made for such repair or replacement.

**Service and Repair:** Should the appliance malfunction, you should first call toll-free 1 (800) 233-9054 between the hours of 9:00 am and 5:00 pm Central Standard Time and ask for CONSUMER SERVICE stating that you are a consumer with a problem. Please refer to model number SEAT6 when you call.

**In-Warranty Service (USA):** For an appliance covered under the warranty period, no charge is made for service or postage. Call for return authorization 1 (800) 233-9054.

**Out-of-Warranty Service:** A flat rate charge by model is made for out-of-warranty service. (Include \$6.00 (U.S.) for return shipping and handling. We will notify you by mail of the amount of the charge for service and require you to pay in advance for the repair or replacement.

**For Products Purchased in the USA, but Used in Canada:** You may return the product insured, packaged with sufficient protection, and postage and insurance prepaid to the USA address listed below. Please note that all customs duty / brokerage fees, if any, must be paid by you and we will require you to pay the cost of customs duty / brokerage fees to us in advance of our performing any service.

**Risk During Shipment:** We cannot assume responsibility for loss or damage during incoming shipment. For your protection, carefully package the product for shipment and insure it with the carrier. Be sure to enclose the following items with your appliance: any accessories related to your problem, your full return address and daytime phone number, a note describing the problem you experienced, a copy of your sales receipt or other proof of purchase to determine warranty status. C.O.D. shipments cannot be accepted.

To return the appliance, ship to:

ATK: Repair Center  
Salton, Inc.  
708 South Missouri Street  
Macon, MO 63557

To contact us, please write to, call, or email.

Salton, Inc.  
P.O. Box 1637  
Columbia, MO 65205-1637  
1-800-233-9054  
E-mail: Salton@Saltonusa.com

**Limitation of Remedies:** No representative or person is authorized to assume for Salton, Inc. any other liability in connection with the sale of our products. There shall be no claims for defects or failure of performance or product failure under any theory of tort, contract or commercial law including, but not limited to negligence, gross negligence, strict liability, breach of warranty and breach of contract. Repair, replacement or refund shall be the sole remedy of the purchaser under this warranty, and in no event shall Salton be liable for any incidental or consequential damages, losses or expenses. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

**Legal Rights:** This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

For more information on Salton products, visit our website: [www.eSalton.com](http://www.eSalton.com)

©2003 Salton, Inc. All rights reserved.

Made in China

P/N 61447

12/03