


OWNER'S MANUAL
Model No. SK2

Smokeless Ashtray



salton®

Get a taste of the good life with Salton.

Getting To Know Your SK2 Smokeless Ashtray

1. Remove upper smoke shield from the top of the unit. Remove second ashtray cover. (See Figure 1.) Insert 2 sized "C" batteries and snap into place indicated by markings "+" and "-" inside battery compartments. Replace both covers.
2. To use ashtray, turn switch on the side of the unit to the "ON" position. The fan will begin to operate and begin to filter smoke through the activated carbon filter, helping to protect others from second-hand smoke.
3. To turn fan off, turn switch to "OFF" position on the side of the unit.
4. To clean the ashtray, remove the cover and wash with warm, soapy water. Dry completely before returning to the unit.
5. The life of the carbon filter is approximately 75 days. To remain effective, the filter should be replaced at this time. For replacement parts, please call 1-800-233-9054.




Figure 1




Figure 2

- | | |
|-----------------------|------------------------|
| 1. Upper Smoke Shield | 4. Battery Compartment |
| 2. Ashtray Cover | 5. Carbon Filter |
| 3. Fan | 6. On/Off Switch |

ONE-YEAR LIMITED WARRANTY

This Salton/MAXIM product warranty extends to the original consumer purchaser of the product.

Warranty Duration: This product is warranted to the original consumer purchaser for a period of one (1) year from the original purchase date.

Warranty Coverage: This product is warranted against defective materials or workmanship. This warranty is void if the product has been damaged by accident, in shipment, unreasonable use, misuse, neglect, improper service, commercial use, repairs by unauthorized personnel or other causes not arising out of defects in materials or workmanship. This warranty is effective only if the product is purchased and operated in the USA, and does not extend to any units which have been used in violation of written instructions furnished by Salton/MAXIM Housewares, Inc., or to units which have been altered or modified or to damage to products or parts thereof which have had the serial number removed, altered, defaced or rendered illegible.

Warranty Disclaimers: This warranty is in lieu of all warranties expressed or implied and no representative or person is authorized to assume for Salton/MAXIM Housewares, Inc. any other liability in connection with the sale of our products. There shall be no claims for defects or failure of performance or product failure under any theory of tort, contract or commercial law including, but not limited to, negligence, gross negligence, strict liability, breach of warranty and breach of contract.

Warranty Performance: During the above one-year warranty period, a product with a defect will be either repaired or replaced with a reconditioned comparable model (at Salton/MAXIM's option) when the product is returned to the Salton/MAXIM facility. The repaired or replacement product will be in warranty for the balance of the one-year warranty period and an additional one-month period. No charge will be made for such repair or replacement.

Service and Repair

Should the appliance malfunction, you should first call toll-free 1-800-233-9054 between the hours of 9:00 am and 5:00 pm Central Standard Time and ask for CONSUMER CUSTOMER SERVICE stating that you are a consumer with a problem.

In-Warranty Service: For an appliance covered under the warranty period, no charge is made for service or postage. Call for pre-paid return mailing label. (U.S. Customers Only)

Out-of Warranty Service: A flat rate charge by model is made for out-of-warranty service. Include \$6.00 for return shipping and handling.

Salton/MAXIM cannot assume responsibility for loss or damage during incoming shipment. For your protection, carefully package the product for shipment and insure it with the carrier. Be sure to enclose the following items with your appliance: any accessories related to your problem; your full return address and daytime phone number; a note describing the problem you experienced; a copy of your sales receipt or other proof of purchase to determine warranty status. C.O.D. shipments cannot be accepted.

Return the appliance to:

ATTN: Repair Department
Salton/Maxim Housewares, Inc.
550 Business Center Drive
Mt. Prospect, Illinois 60056

1995 Salton/MAXIM Housewares, Inc.